

# Reliance®



**Reliance Cool Muscle**  
An Intelligent Integrated Servo System

## User's Guide




## Copyright

Copyright 1982-2005 Myostat Motion Control Inc. All rights reserved.

This User Manual is copyrighted by Myostat Motion Control Inc.  
All rights reserved.

Information on this document is subject to change without notice.

Cool Muscle is a trade mark of Muscle Corporation. Microsoft and Windows 98/2000/ME are registered trade marks of Microsoft Corporation. All other product names are copyrighted and registered trademarks or trade marks of their respective holders. All computer and software names identified by TM are trade marks of their respective manufacturers.





PREFACE TO THE USER MANUAL.....	6
Reliance Cool Muscle.....	6
Disclaimer .....	6
 SECTION 1	
SET UP PROCESS .....	8
 SECTION 2	
WHEN YOU RECEIVE RELIANCE COOL MUSCLE .....	10
Do you have.....	10
Components .....	11
Communication with the Reliance Cool Muscle .....	12
 SECTION 3	
SETTING UP RELIANCE COOL MUSCLE .....	14
How To Connect The Reliance Cool Muscle .....	14
 SECTION 4	
INPUT AND OUTPUT.....	18
Pin Assignment and Layout.....	18
Wiring Examples .....	22
 SECTION 5	
CML .....	27
STRUCTURE .....	27
What is CML?.....	27
Parameters.....	27
Commands .....	28
CML Structure .....	28
 CML File Structure.....	30
CML Program File Example .....	31
CML File Structure - Dynamic Command Mode.....	31
CML File/Command Downloading.....	32
 SECTION 6	
HOW TO USE COOL WORKS .....	33
How To Use Terminal Window.....	34
Terminal Window Function Buttons .....	34

**SECTION 7**

<b>SETTING PARAMETERS .....</b>	38
Before setting parameters.....	38
Parameter Structure.....	39
Parameters .....	39
Input/Output .....	39
Input Logic	
Resolution .....	47
Origin.....	47
In-position.....	50
In-position.....	50
Making the motor stop.....	50
Deceleration .....	51
Manual Motion.....	52
Gain Adjustment.....	52
Pulse Type Reliance Cool Muscle.....	54
Analog Type Reliance Cool Muscle .....	55
Analog Distance Range .....	55
Low Pass Filter.....	56
Push Mode .....	56
Creeping Speed .....	57
Communication Speed.....	58
Semi-Closed/Full-Close Loop Mode .....	58
Motor Status Report Style .....	59
 PROGRAM MODE COMMANDS.....	60
Motion Commands - define motion .....	60
Basic CML Program Examples .....	71
Basic Point to Point motion .....	71
Continuous Point to Point motion with different speeds.....	72
Continuous Point to Point motion with different speeds and accelerations.....	72
Point to Point motion with different deceleration .....	73
Push Mode .....	73
Networking Reliance Cool Muscles .....	74
Defining Motion for multiple motors.....	74
How to create network programs .....	75


**SECTION 9**

<b>Dynamic Mode Commands .....</b>	77
<b>Motion Commands .....</b>	77
<b>Execution Commands .....</b>	78

---

**SECTION 10**

Applied CML Program .....	81
Appendix1.....	90
Reliance Cool Muscle Dimensions .....	90
Reliance Cool Muscle Specifications .....	91
Input/output Signal .....	92
Connection Diagram .....	93
Appendix 2.....	94
Parameters .....	94
Appendix 3 .....	100
Program Mode - Motion Commands .....	100
Program Mode - Execution Commands .....	102
Other commands .....	103
Dynamic Mode - Motion Commands .....	103
Dynamic Mode - Execution Commands .....	103
Save and Inquiry Commands .....	104
Appendix 4 .....	105
Network Card Specifications .....	105
Appendix 5 .....	106
Custom Interface Cable.....	106
Appendix 6 .....	107
Index Signal .....	107
Appendix 7.....	108
RS-485 Communications .....	108
Appendix 8 .....	111
Analog Input Functions in the C-Type Reliance Cool Muscle .....	111
Appendix 9 .....	112
Using the H Infinity Auto Tuning Module (V2 Firmware).....	112



# PREFACE TO THE USER MANUAL

Welcome to the Reliance Cool Muscle integrated motor. This user manual provides you with hands-on instructions to help you set up your hardware, set parameters, create or edit command programs and make the most of the Reliance Cool Muscle motors.

## Reliance Cool Muscle

The Reliance Cool Muscle is a fully integrated closed loop vector drive servo system. With an intelligent driver, a 32-bit RISC CPU, a magnetic encoder and power management built onto the motor, the Reliance Cool Muscle excels in performance, size and cost.

Supporting a wide variety of communication interfaces including USB, RS-232, Pulse ( CW/CCW and Step/Direction) and Variable Voltage, the Reliance Cool Muscle can be used not only for new products but also for replacing or upgrading the current systems.

The Reliance Cool Muscle's high resolution encoder gives you the exceptional resolution of 50,000 pulses/rotation. Combined with vector drive control, the Cool Muscle is an incredibly smooth and quiet motor.

Using CML (Cool Muscle Language), you can easily set parameters and create motion programs that can be downloaded directly onto the motor. (C type motors only)

## Disclaimer

Before operating the Reliance Cool Muscle, it is very important that you read this user manual thoroughly. The Reliance Cool Muscle can cause bodily injury and/or equipment damage if it is misused. Proper safety means and measures should be provided to prevent any misuse and/or improper operations. The user assumes all liability.



ty for its use. The Reliance Cool Muscle shall not be used for mission critical applications without explicit written permission from Reliance Precision Mechatronics LLP and the Muscle Corporation.



Do not impact the motor.

Impacting the motor may cause the driver case and the sensor mounted on the back of the motor to move, resulting in alignment errors.



Do not rotate the shaft of the motor when it is not powered on. Rotating the shaft over 400RPM when the motor is not powered on may cause regenerated voltage within the motor. This regenerated voltage may damage the driver board.



Use Regulated power supply

Please make sure to use a regulated DC24V power supply. Sudden spikes from non-regulated power supplies may cause damage to the motor.



Do not use the motor in wet conditions

Standard Reliance Cool Muscle motors are not environmentally sealed. Using the motor in wet conditions may damage the motor.



Use the motor within its specification

Please refer to the spec section of this manual and ensure that the motor is used within these specifications.



Are your cables too long?


The recommended length of motor cable is 3m and the power cable is 2m. If longer cables are required, please follow the instructions in this manual.



Do not connect or disconnect the motor connector when the motor is powered on. This may damage the motor.



## SECTION 1



# SET UP PROCESS

This section takes you through a typical Reliance Cool Muscle set up process. Since this User Manual is organized to follow the set up process described in this section, you can always refer back to this section.

### Step 1

Refer to the sections applicable to your Motor Type

- P** Pulse Type
- V** Analog Type
- C** Computer Type

When you receive the Reliance Cool Muscle

**P** **V** **C**

When you receive a Reliance Cool Muscle package, make sure that you have all the components you need or ordered. Connect the motor to your PC and make sure that there is proper communication between the motor and your PC.

See Section 2

### Step 2

Connect Reliance Cool Muscle Cables

**P** **V** **C**

See how the Reliance Cool Muscle is connected using supplied cables. Learn about each component included in a standard Reliance Cool Muscle package.

See Section 3

### Step 3

Learn I/O settings

**P** **V** **C**

Learn how to control I/O ports and set functions for each I/O port.

See Section 4



#### Step 4

##### Lean about CML

P V C

Learn how CML (Cool Muscle Language) is structured.

See Section 5,6

#### Step 5

##### Set Parameters

P V C

Set parameters to make the Reliance Cool Muscle suit your specification. Learn how to set the parameters. This section also lists all the parameters available.

See Section 7

#### Step 6

##### Create/Edit/Execute Motion Programs

C

Learn all Program mode CML commands and how to create motion programs with parameters, I/Os and commands. Useful basic examples are described.

See Section 8


#### Step 7

##### Operate Reliance CM with Dynamic Commands

C

Learn how to operate Reliance Cool Muscle using Dynamic CML commands.

See section 9



## SECTION 2

# WHEN YOU RECEIVE RELIANCE COOL MUSCLE

When you receive a Reliance Cool Muscle package please make sure that you have all the components you ordered. You may then proceed to the next step and connect the motor to your PC to make sure that you have proper communications.

## Do you have...

The components that you need to operate the Reliance Cool Muscle are listed in the green area in the table below. The components listed in the pink area are optional components used for networking ing the Reliance Cool Muscles.

Components /Reliance Cool Muscle Type	Pulse Type	Analog Type	Computer Type
Reliance Cool Muscle Motor	O	O	O
Motor Cable	O	O	O
Y Cable	Option	Option	Option
24V Reliance CM Power Supply	Option	Option	Option
Free Software*	O	O	O
Network Card (master set)	Option	Option	Option
Network Card (slave set)	Option	Option	Option
D-sub 9pin network cable (straight male-female)	Option	Option	Option

O=included with the motor

Option=optional component

CM=Cool Muscle

\* Available to download free at [www.rpmechatronics.co.uk](http://www.rpmechatronics.co.uk)



## Components

### Motor Cable

The Reliance Cool Muscle comes with one motor cable. The standard length of the motor cable is 40cm. Longer cables are available.



### Y Cable

A Y cable is required to connect the motor to a RS-232C port on a PC. This cable is required when downloading motor parameters, and motion programs onto the Reliance Cool Muscle, or when you wish to control a single motor via serial communication. Contact our sales team on +44 (0) 1484 601002 or visit [www.rpmechatronics.co.uk](http://www.rpmechatronics.co.uk)



### Power Supply

A regulated 24V (DC) power supply. Required power supplies are available from Reliance Precision Mechatronics.



### Network Card and Serial Daughter Card

The Network Card allows you to daisy chain the Reliance Cool Muscles. A master motor requires a serial daughter board in addition to the network Card. The Network Card can also be used as a voltage clipper. D-Sub 9 pin cables ( straight) are required to inter-connect the Reliance Cool Muscles and to connect a PC and master motor.






## Communication with the Reliance Cool Muscle

Connect the Reliance Cool Muscle to your PC to make sure that your PC can communicate with the motor. Please follow the steps below. A trouble shooting section is included on the next page.

1. Connect the Y cable to the Reliance Cool Muscle, your PC and a 24VDC power supply. ( refer to Section 3 "Setting Up Reliance Cool Muscle")  
Make sure that the power is turned OFF.
2. Start up your PC
3. Start up Cool Works Lite. Cool Works Lite can be downloaded free from [www.rpmechatronics.co.uk](http://www.rpmechatronics.co.uk)
4. Power the motor on. Motor information should appear. If motor information is displayed you are ready to talk to the motor!



5. Check the preloaded parameters by entering ?90 and press the Enter key. Parameters (starting with K25) should appear in the motor reply window. These are the preloaded parameters.
6. Turn off the motor and close Cool Works Lite



## Trouble Shooting

### Nothing appears when the motor is powered on.

- Is the Reliance Cool Muscle Powered on? Make sure that the motor is not in motor free state. If it is turn the power off and then turn it on.
- Do you have multiple terminal applications running in the background? Or do you have software for PDAs or other programs that occupy COM ports running? Make sure that these programs are disabled and not running in the back ground.

### Nothing appears when ?90 is entered.


Parameters are not properly displayed. Turn the motor off and on. If the motor responds with its version information, communication is established.

You can load default parameters with the MotorReset software available to download free from [www.rpmechatronics.co.uk](http://www.rpmechatronics.co.uk)

1. Start MotorReset software.

2. Click Reset Motor to load the default parameters. Then, click Test Motor to make sure that the Reliance Cool Muscle operates properly. Click Stop Motor to stop the Reliance Cool Muscle.






## SECTION 3

# SETTING UP COOL MUSCLE

## How To Connect The Reliance Cool Muscle Using Y cable



Do NOT connect or disconnect the motor while it is powered on.



## Using Network Cards

You can network multiple motors by using network cards.



Instead of using the Y cable, you can use the network card and the interface card to connect the Reliance Cool Muscle to a PC. You need aD-Sub 9 pin straight cable

## What Do I need to Create a Daisy Chain?

1. Network Card
2. Serial Interface Card
3. Motor Cables
4. D-Sub 9 pin Straight cables
5. DC+24V Power Supply
6. Power Cable



Network Card



Serial Interface Card



## Jumpers

Before you connect the network and interface cards, you need to set the jumpers.

### Network Card


#### Jumper 1&2

These jumpers are for switching the DC+24V line on the card.

- Leave JP1&JP2 open when power is supplied through the terminal block on the card.
- Close JP1&JP2 when power is supplied via the serial cable.

#### Jumper 3,4&5

- Connect Pin 2 and 3 of each Jumper when a Serial Daughter Card is attached to the network card (Master Network Card - CM1DC1-MBS).
- Connect Pin 1 and 2 when a Serial Daughter Card is NOT attached to the network card. (Slave Network Card - CM1DC1-SBS)






### Interface Card

JP1 and JP2 on the interface board allow you to switch between RS232 and RS485.

JP1	RS232 Connect Pin 1&2
JP2	Connect Pin 2&3
JP1	RS485 Connect Pin 2&3
JP2	Connect Pin 1&2




### How to Connect the Network Card and the Interface Card

To daisy chain the Reliance Cool Muscles, you need network cards and an interface card. A master motor which will be connected to a host computer needs both the network card and the interface card. Slave motors need only the network card.

### Master Motor


Attach the interface card to the network card.





Connect the Network card as below.


Connect to host computer via a serial cable



Connect to the next Reliance Cool Muscle via a serial cable

#### Slave Motor

Connect to the previous Reliance Cool Muscle via a serial cable




Connect to the next Reliance Cool Muscle via a serial cable

Note: Power may be transferred from card to card via the DB9 connectors as noted on page 16.



## SECTION 4



# INPUT AND OUTPUT

## Pin Assignment and Layout

The Reliance Cool Muscle has 4 inputs and 2 outputs that are user definable. Each I/O port can be assigned multiple functions by setting motor parameters using CML. (Please refer to the Parameter section)

### Connector Pin Layout



Pin#	Function	Return Pin	Assinable I/O types
1	DC+24V		N/A
2	GND-1		N/A
3	Input 2-		N/A
4	Output 2	11	Digital Out Analog Out Serial Transimit(TX)
5	Output 1	11	Digital Out Analog Out Serial Transimit(TX)
6	Input 4 (max 5V)	11	Digital In Analog In
7	Input 3 (max 5V)	11	Digital In
8	Input 1-		N/A
9	Input 2	3	Digital In Pulse Counter Serial Receive(RX)
10	input 1	8	Digital In Pulse Counter Serial Receive(RX)
11	GND2		N/A
12	DC+5 Out		N/A



## Assignable functions - Input

### Digital Input

Multiple functions can be assigned to a digital input port. A time delay can be set to create a 'slow response' signal, or a time delayed virtual signal based on a real signal (Quick Response signal). Actions can be performed for the duration (or at the target voltage level) of the input or at both the rising and the falling edges of either the quick or the slow response signals. This provides 6 different states. Each state also has multiple features that can be assigned to it.

#### ***Assignable input functions at the target voltage level***

#	Function
0	No Action
1	General Use
2	Origin Sensor
3	Manual Feed CW
4	Manual Feed CCW
5	Switch in-position signal to Index signal

#### ***Assignable input functions at the rising and <falling> edges***

#	Function
0	No Action
1	Reset Alarm/Pause
2	Motor Free <Enable Motor>
3	Reset Counter
4	Execute next step
5	Execute previous step
6	Execute Bank 1
7	Go Origin
8	Manual Jog CW
9	Manual Jog CCW

#### ***Example:***

Input 1 is configured to be

K28=0008

K30=0003

1. Manual Jog on the rising edge of a quick response signal.

2. Manual Feed for the duration of a slow response signal.

When a quick response input signal is detected, the motor will jog a distance defined by K50. When a slow response signal is detected, the motor feeds for the duration of the signal (K49).

**Pulse Counter**

CW/CCW

Step/Direction

**Serial Input**

Serial Communication

**Analog In**

Speed

Position

**Input ports and assignable Input types**

I/O	Digital In	Analog In	Pulse In	Serial In
Input 1	OK	NO	OK	OK
Input 2	OK	NO	OK	OK
Input 3(Max 5V)	OK	NO	NO	NO
Input 4(Max 5V)	OK	OK	NO	NO

OK: assignable

NO: not assignable

**Assignable functions - Output****Digital Output*****Assignable Output Functions***

#	Function
0	Command
1	In-Position
2	Alarm
3	Analog Out
4	General Use 1
5	General Use 2
6	In-Position Output in Merge Mode



### Analog Output

#	Analog Output Types
0	Target Position
1	Target Position magnified by 8
2	Current Position
3	Current Position magnified by 8
4	Position Error
5	Position Error magnified by 8
6	Current Velocity
7	Current Velocity magnified by 8
8	Current Torque
9	Current Torque magnified by 8

### Serial Output

Serial Transmit to Host

Serial Transmit to Slave

### Output ports and assignable Output types

I/O	Digital Out	Analog Out	Serial Out
Output 1	OK	OK	OK
Output 2	OK	OK	OK


OK: assignable




## Wiring Examples

### CW/CCW or Step/Direction

#### 1. Linedriver



#### 2. Open Collector







## Digital Input :Switch and PLC

### Input 1

#### **Switch**




#### **PLC**




### Input 2

#### **Switch**



#### **PLC**






## Digital Input : Switch and PLC


### Analog Input

Input 3 ( Max 5V)


#### **Switch**



#### **PLC**




#### **Analog**






Input 4(Max 5V)


**Switch**



**PLC**



**Analog**







## Output

Output1

**Digital Output**




**Analog Output**





Output2

**Digital Output**



**Analog Output**






## SECTION 5

# CML STRUCTURE

### What is CML?

CML(Cool Muscle Language) consists of a set of ASCII commands that provide a means to easily create motion programs for single or multi-axis systems. As the CML command structure allows commands to be identified by Motor ID, multiple networked Reliance Cool Muscles can be controlled via I/O or from a PC.



### Parameters

Set parameters using CML. You can easily change parameters to suit your specifications.

Parameter Definition:

Parameter definitions take the form of:

K#=VALUE

K# signifies the parameter number to be set and VALUE represents the data to be assigned to K#. A list of parameters and their corresponding numbers are outlined in the Setting Parameter Section (Section 7).



ie.

K37=4

This parameters sets motor resolution to 2000 pulses per rotation.

## Commands


There are two command modes:

1. Program Command mode: used to create motion programs that can be downloaded to the Reliance Cool Muscle.
2. Dynamic Command mode: directly operate the motor via a PC to cause immediate action.

## CML Structure

### Command Structure and Rules

The basic structure of a CML command is:



#### Command Memory Location

Some commands have a limited number of memory locations.

For example, Position and Speed can be stored in 25 and 15 memory locations respectively. Specify the memory location for the corresponding value.

P14.3=1000

The defined value 1000 is stored in position memory location 14 on Motor 3. The value set by the parameter is absolute.

#### Modifier

Modifiers exist in limited cases. The most common modifier is the relative motion modifier, + which is used with the P com-



mand. Adding + after the memory location makes the value relative. P14+.3 would command motor 3 to move relatively or incrementally the distance of 10000, which has been previously stored in Position Memory location 14.

#### **Motor ID**

When you wish to program multiple motors, you can specify a Motor ID as part of the CML command. The commands and parameters will be placed in the memory locations of the specified motor. When Motor ID is omitted, it is assumed to be either motor 1 or the last ID value used.

#### **Value**

The value defined in the command structure above is absolute. Values are typically used at the beginning of a CML program file to place values into the motors permanent memory. As an example, P14.3=10000 would place the value of 10000 into the Position memory location 14 of motor 3.

#### **Spaces**

Spaces should not be used in a command line.


#### **Upper or Lower Case?**

All the commands in CML program files are not case sensitive.



## CML File Structure

CML files are made of 2 different parts. The first part defines memory contents while the second part defines motion programs. Some aspects of a motor's movement or control are defined by parameters. Speed and Acceleration data must be stated before the first target position. Subsequent moves will be based on previously stated Acceleration and Speed unless otherwise commanded.



### Motion Definitions

Position, Speed, Acceleration and Timer definitions take the form of:

```
P#=VALUE  
S#=VALUE  
A#=VALUE  
T#=VALUE
```

### CML Program Banks

Program Banks are made up of CML Motion Commands. Program Banks can be stored in the motor's EEPROM. A program bank is defined as follows:

B# (carriage return)

B# specifies the program bank number. Each program bank can be regarded as an object. Program Banks may contain up to approximately 100 steps. CML Commands and their structures are outlined in the CML Command Listing.



## CML Program File Example

```
K26=1111/SET INPUT LOGIC
K49=15/SET MANUAL SPEED
K58=500/SET SOFTWARE LIMIT CW
K59=-500/SET SOFTWARE LIMIT CCW
P1=1000/SET POSITION MEMORY CONTENTS
P2=2000
P3=5000
S1=200/SET SPEED MEMORY CONTENTS
S2=1000
A1=200/SET ACCELERATION MEMORY CONTENTS
A2=100
B1/FIRST PROGRAM BANK
C2
C3/JUMP TO THE BEGINNING OF PROGRAM BANK 3
B2 /SECOND PROGRAM BANK
S1,A2,P1/SET SPEED, ACCELERATION AND POSITION
S2,P2
P3,P2,S1,P1/PERFORMS A SMOOTH MOVEMENT FROM
POINT TO POINT WITH STOPPING AND WITH A CHANGE IN
SPEED BETWEEN P2 AND P1
B3/THIRD PROGRAM BANK
S1,P3
(For more detailed information please refer to "Programming
with CML")
```

## CML File Structure - Dynamic Command Mode

Dynamic Commands cause immediate action. This mode is typically used for debugging and non-repetitive movements.

Dynamic Command structure:

S=value  
A=value  
P=value  
^ (execute)



In Program mode, you need to define position, speed, acceleration and timer. In Dynamic Command mode, you can directly drive the motor by entering motion profiles.

ie.

S=1000  
A=200  
P=10000  
^

## CML File/Command Downloading

There are a number of ways to use CML to set parameters, define motion, create programs, execute programs, drive motors and download programs onto the motor. Cool Works is free software designed to work with CML. You can also use Hyper terminal which usually is included with your Windows installation disk. Default Serial Communication specs are: 38.4Kbs, 1 Stop bit, No Parity, No Handshaking.

Changing Parameters, execute program banks, drive motor in dynamic command mode.

Directly enter commands in a terminal program such as Cool Works or Hyper terminal.

Creating and editing program banks.

It is recommended that a text editor is used to create and edit complicated program files. Make sure you save program files as a plain text file. You can download program files to the Reliance Cool Muscle via a terminal program by importing text files. You can also load parameters in the same method.

Any parameters specified in the file are changed in the motor without affecting unspecified parameters. All program banks are erased and replaced with the program banks specified in the CML file. When you want to write the program into the motor's EEPROM, enter a "\$". K Parameters are stored automatically.



---

## SECTION 6

# HOW TO USE COOL WORKS

Select COM port: This is where you select COM port that the Reliance Cool Muscle is connected to.

1. Start up Cool Works by clicking on the Cool Works icon.



CoolWorks


2. The window below will appear. Select the COM port that the Reliance Cool Muscle using. By selecting the COM port, the Terminal Window/Setting Window/Jog Window buttons will be activated. In the Terminal window, you can communicate with the Reliance Cool Muscle directly. In the Motor Browser window, parameters specific to each motor type (P,C) can be easily set. The Jog window lets you manually operate the Reliance Cool Muscle.



3. Check the RS-232 port to ensure the Reliance Cool Muscle is connected. Power the Reliance Cool Muscle.

# How To Use Terminal Window

After selecting the COM port, a terminal window will appear. In this window, you can manually set parameters, create motion programs, save to EEPROM, read parameters in the Reliance Cool Muscle, and operate the Reliance Cool Muscle in dynamic mode.



## Terminal Window Function Buttons

Go to Origin: Make the motor go origin (Position 0)

**Set as Origin:** Set the current position to 0.

Enable motor: Enable motor in a motor free state.

**Free Motor:** Turn the motor into a motor free state.

CML Values

Positions: displays position data stored in the motor.

Speeds: displays speed data stored in the motor.

Accelerations: displays acceleration data stored in the motor.

Timers: displays timer data stored in the motor.

Dynamic Values: displays dynamic values of P, S, and A.

Motor settings: displays motor parameters from K25 to K63.


## Current Status

## Select Program Bank



- Alarm: displays alarm state
- Torque: displays current torque
- Position: displays current position
- Error: displays positon error
- Speed: displays current speed

## Execute Bank Program



### Opening from existing CML files

You can open exiting CML files. Go the Menu Bar and select Files and Open. Select the file you want to use in Cool Works and click Open. The content of the file will be displayed in the Entry window. Click Send to send to the motor. Files need to be saved as a .txt file.


### Switching to another window

By clicking the icons on the menu bar, you can easily switch windows.




## How Use Jog Window

In the Jog Window, you can manually operate the Reliance Cool Muscle. The maximum speed, Acceleration are defined by the resolution and speed unit you set in this window.



Changing the resolution or speed unit in the Job Window immediately overwrites the existing setting in the motor. Hold and drag the speed scroll bar to operate the motor. To move the motor to position 0, click the Go Origin button.





## SECTION 7

# SETTING PARAMETERS

## Before setting parameters

To set parameters on the Reliance Cool Muscle, you need to connect the motor to a PC via the Y cable or the network card. You can set parameters on multiple motors when the motors are networked via network cables.

### Using Y cable

Connect the Reliance Cool Muscle ( refer to Section 3 “How to connect Reliance Cool Muscle”). Start up Cool Works or a terminal program and turn the motor on. Make sure that there is communication established between the Cool Muscle and your PC. (Please refer to Section 6 “How to use Cool Works” )

### Using Network cable

Connect the Reliance Cool Muscle ( refer to Section 3 “How to connect Reliance Cool Muscle”). Start up Cool Works or a terminal program and turn the motor on. Each motor is automatically given a motor ID. Make sure that there is communication established between the Reliance Cool Muscle and your PC. (Please refer to Section 6 “How to use Cool Works” )

### Quick Reference Guide

*A Quick Reference sheet is provided at the back of this manual, or as a PDF that can be downloaded from [www.rpmechatronics.co.uk](http://www.rpmechatronics.co.uk)*



## Parameter Structure

Parameters are defined at the beginning of a CML program file.  
Each parameter is assigned a memory location.

To set a parameter, follow the structure below.

K # =Value

Example;

K50=15

(Distance for Manual Jog is set to 15 pulses)

## Parameters

This section provides detailed information on each parameter.  
For a quick reference please use the parameter summary table  
in Appendix 2.

### Input/Output

#### Input Logic

K26

##### ***Descriptions***

This parameter sets the input logic.



The target voltage level can be either less than 0.8V or more than 3V. When input logic is set to true = low, the target voltage is less than 0.8. When it is set as true = high, the target level is more than 3V (7mA min.).

Min.	Max.	Default	Descriptions
0000	1111	0000	0: normally open 1: normally closed

\*Each number represents Input pin #4, 3, 2, 1 ordered from the right to left. ie. K26=0100

Input 4 = normally open

Input 3 = normally closed

Input 2 = normally open

Input 1 = normally open



## Offset for Slow Response Signals

K25

**Descriptions**

This parameter sets the time delay to create two sets of signals, quick response and slow response signals. If the signal is completed within the set time delay period, it is only recognized as a quick response signal and not recognized as a slow response signal.


Min.	Max.	Default	Unit
1111	9999	3333	0.1 sec

\*Each number represents Input pin #4, 3, 2, 1 ordered from the right to left.  
ie.K25=0100


**Quick and Slow response time offset**

A quick response signal starts when it hits the high point.


A slow response signal starts after the time offset set by the parameter (in this example it is set to 0.2sec).

**Quick and Slow response event triggers**

Events (functions) can be assigned to the rising (and falling edges and the target voltage level of a quick and slow response signals.

**Short Signal**

When a signal is completed within the offset time only a quick response signal is recognized.



**Input Functions at the Target Voltage Level: Quick Response Signal (QTV)**

K27

**Input Functions at the Target Voltage Level: Slow Response Signal (STV)**

K30

**Description**

This parameter assigns a function performed for the duration of a signal. Assignable functions are listed in the table on the next page.

**Assignable Functions for the target voltage level**

#	Function	Descriptions
0	No Action	
1	General Use	Typically used for the I command. For example, B1 I2, C2, C3 When input 2 is true then execute bank 2 otherwise execute bank 3.
2	Origin Sensor	
3	Manual Feed CW	Motor turns in a CW direction for the duration of the signal
4	Manual Feed CCW	Motor turns in a CCW direction for the duration of the signal
5	Switch in-position signal to Index signal	When an output is set to in-position by parameter 34, it signals in-position when the motor reaches the target position. When the motor reaches the origin, it sends out index signal. Refer to Appendix # for details.
6	Execute Bank 1	Used to Execute Bank 1 on startup of motor
7	Emergency Stop	Stops the motor immediately and inhibits motion execution
8	Full Stop	

<b>Min.</b>	<b>Max.</b>	<b>Default</b>
0000	5555	0000(K27)
0000	5555	0000(K30)

\*Each number represents Input pin #4, 3, 2, 1 ordered from the right to left.

ie. K27=0100



Input Function at the Rising Edge:  
Quick Response Signal (QR)

K28

Input Function at the Falling Edge:  
Quick Response Signal (QF)

K29

Input Function at the Rising Edge:  
Slow Response Signal (SR)

K31

Input Function at the Falling Edge:  
Slow Response Signal (SF)


K32



Functions that create motion should be limited to Input 3 and 4 for safety reasons. Inputs 1 and 2 are also used for serial communications. When connected to a serial port, the voltage used in the serial protocol might activate any function assigned to these ports.

#### Description

This parameter assigns a function performed at the edges of a signal. Functions or events should be assigned to event triggers in such a way as to make sense. For example, it may create undesirable movements if you assign Motor Free to the rising edge of a quick signal and Go origin to the duration of a slow response signal. With this input function assignment, when the motor is commanded to go back to origin, as it goes into a free state at the rising edge of a quick response signal, it will not be able to go back to origin.





**Assignable Functions at the rising and falling edges of an input signal**  
**Functions with < > indicate functions for the falling edge only**

#	Function	Descriptions
0	No Action	
1	Reset Alarm/Pause	Reset Alarm: When alarm is on, it resets the alarm. Pause: Pauses the motor. Send a start signal to resume the motion.
2	Motor Free <Enable Motor>	Makes the motor go into a motor free state. <Enables the motor from a motor free state>
3	Counter Reset	Makes the current position 0
4	Execute next step	Execute the next program line. This function is used when executing line by line within a program bank.
5	Execute previous step	Executes the previous program line.
6	Execute Bank 1	
7	Go Origin	
8	Manual Jog CW /Execute Bank 2	Motor turns in a CW direction the distance set by parameter 50. Set speed by parameter 49. Acceleration set by 42 (Also used for Origin Search acceleration) is applied.  When K36 is set to 2 8 becomes Execute Bank 2 instead of Manual Jog CW
9	Manual Jog CCW /Execute Bank 3	Motor turns in a CCW direction the distance set by parameter 50.  When K36 is set to 2 9 becomes Execute Bank 3 instead of Manual Jog CCW

Min.	Max.	Default
0000	9999	0100(K28)
0000	9999	0000(K29)
0000	9999	0200(K31)
0000	9999	0300(K32)

\*Each number represents Input pin #4, 3, 2, 1 ordered from the right to left.

ie.K28=0100(Input 4=0, Input 3=1, Input 2=0, Input1=0)



## Output logic

K33

**Descriptions**

This parameter sets the output logic.

Min.	Max.	Default	Description
00	11	11	0: Normally Open 1: Normally Closed

\*Each number separated by a comma represents Output pin #2,1 ordered from the right to left. When typing in parameters, you don't need commas. ie. K33=01

## Output Functions

K34

**Description**

This parameter assigns a function to an output. Assignable functions are as below.

#	Function	Descriptions
0	Command	
1	In-Position	Sends out an in-position signal when the motor reaches the target position.
2	Alarm	
3	Analog Out	Outputs analog waves for monitoring. Choose a type of information by parameter 35.
4	General Use1	
5	General Use 2	
7	Timed Trigger	Outputs a signal at certain intervals. Timing is set by K24
8	Motor Free	
9	Torque Limit Reached	For Push mode

Min.	Max.	Default
00	66	21

\*Each number separated by a comma represents Output pin #2,1 ordered from the right to left.  
ie.K33=01



## Interval for Timed Trigger

K24

**Description**

This parameter lets you set the distance interval for timed trigger .

Min.	Max.	Default	Unit
10	32767	1000	pulses


## Analogue Output Functions

K35


**Description**

This parameter lets you select an analogue output type that you can monitor with an oscilloscope. Make sure that you have selected Analogue Out by parameter 34. The range of analogue output is 0-5V. 2.5V is the baseline. The overall value is cumulative but the analogue output is displayed in the set range (0-5V).

Example :  
current position (3000 pulses)



Example :  
current position (-3000 pulses)



#	Analogue Output Types	Unit
0	Target Position	$\pm 1024$ pulses/ $\pm 2.5V$
1	Target Position manified by 8	$\pm 128$ pulses/ $\pm 2.5V$
2	Current Position	$\pm 1024$ pulses/ $\pm 2.5V$
3	Current Position manified by 8	$\pm 128$ pulses/ $\pm 2.5V$
4	Position Error	$\pm 1024$ pulses/ $\pm 2.5V$
5	Position Error manified by 8	$\pm 128$ pulses/ $\pm 2.5V$
6	Current Velocity	$\pm 2400$ rpm pulses/ $\pm 2.5V$
7	Current Velocity manified by 8	$\pm 300$ rpm pulses/ $\pm 2.5V$
8	Current Torque	$\pm 9.3$ kgfcm pulses/ $\pm 2.5V$ (CM1-x-23L20) $\pm 5.1$ kgfcm pulses/ $\pm 2.5V$ (CM1-x-17L30)
9	Current Torque manified by 8	$\pm 1.16$ kgfcm pulses/ $\pm 2.5V$ (CM1-x-23L20) $\pm 0.64$ kgfcm pulses/ $\pm 2.5V$ (CM1-x-17L30)

Min.	Max.	Default
00	99	31

\*Each number separated by a comma represents Output pin #2,1 ordered from the right to left. ie.K34=21



## Resolution

### Motor Resolution

K37



Parameter values between 20 and 30 should be used when extremely slow speeds are required.

**NEW!**  
K37=100

Improvements in V2 firmware now allow for a resolution of 50000 with a 1pps speed unit.

#### Description

This parameter sets the motor's resolution (pulses/rotation). This parameter also sets the speed unit used by the speed command (S). 0-10 sets the speed unit to 100pps and 20-30 sets the speed unit to 10pps.

Speed Unit 100pps				Speed Unit 10pps			
#	Resolution	#	Resolution	#	Resolution	#	Resolution
0	200	6	5000	20	200	26	5000
1	400	7	10000	21	400	27	10000
2	500	8	25000	22	500	28	25000
3	1000(default)	9		23	1000	29	
4	2000	10	50000	24	2000	30	50000
5	2500			24	2500		

Setting K37=100 sets the resolution to 50000 and the speed unit to 1pps. The entire range of speed is achievable with this setting.

## Homing/Origin Search



The Reliance Cool Muscle will stop during origin search if it does not reach an origin within 5 minute or 80 rotations.

There are two types of origin search routines.

1. Mechanical origin: determined either by an origin switch or bumper.
2. Electrical origin: set by the offset distance from the mechanical origin. Typically used as a home position or starting point.

### Return to Origin Speed

K42

#### Description

This parameter sets the speed when the motor goes back to origin.

Min.	Max.	Default	Unit
1	5000	10	100pps



## Origin Search/Manual Feed Acceleration

K43

**Description**

This parameter sets the acceleration used when the motor returns to origin. This acceleration is also used for manual feed.

Min.	Max.	Default	Unit
1	5000	100	Kpps <sup>2</sup>

## Origin Direction


K45

**Description**

This parameter sets the direction that the origin is located.

#	Direction
0(Default)	CW
1	CCW

If origin search is activated at the point where the origin switch is on, the motor will move in the opposit direction until it sees the edge of the origin switch signal



## Origin Search Method

K46

**Description**

This parameter specifies the method used during an origin search. Origin can be determined using hard-stop/bumper or an origin switch. The motor hits the bumper at very low speed and keeps pushing until it reaches a specified current level (preset by parameter 47). When the current level has reached the set current level, the motor determines that it has found origin. This method eliminates the need for origin switches.



You need to set the following related parameters.

**Stopper:**

Go Origin speed (K42)  
Acceleration (K43)  
Current Level (K47)

**Origin Switch:**

Go Origin speed (K42)  
Acceleration (K43)

#	Method
0 (Default)	Stopper/Bumper
1	Stopper/Bumper (Automatically start origin search when powered on).
2	Origin Switch
3	Origin Switch (Automatically start origin search when powered on).

Current level when searching for origin  
using a stopper

K47

**Description**

Sets the current level at which the motor will determine that the origin position has been reached during a hard-stop origin search routine. It is set by a percentage of the peak current of the motor.

Min.	Max.	Default	Unit
10	100	30	% of the peak current

Offset Distance Between Machine Origin  
and Electrical Origin

K48

**Description**

This parameter sets the offset distance between the mechanical and electrical origin. This parameter is used when you want the motor to find the origin and automatically go to the electrical origin (starting point). If you set the parameter to 0 (default), the



motor stays at the mechanical origin. The speed for moving from the mechanical origin to the electrical origin is set to 2 times as fast as the speed for return to origin.

Min.	Max.	Default	Unit
-32767	32767	0	*100 pulses



In-position Signal is sent out when the motor is within the error tolerance set by K55. If the motor is running at a very low speed and the error tolerance is large, you may see in-position signals even before the motor reaches the target position.

### In-position

#### In-position

In-position signal

K55

#### Description

This parameter sets the error tolerance for an In-Position signal. When the motor is within the specified error tolerance, then an in-position signal will be sent out.

Min.	Max.	Default	Unit
1	100	5	pulses

### Alarms and Limits

Error Counter Over Flow

K56

K56

#### Description

This parameter sets a maximum value for the error counter. If the error exceeds the set value, then the motor goes in to a motor free state.

Min.	Max.	Default	Unit
1	32767	50	Kpulses

Overload time

K57

K57

**Description**

This parameter sets the time delay between the detection of overload and alarm signal output. If you set an even number, the motor will ignore regenerated voltage alarm.

<i>Min.</i>	<i>Max.</i>	<i>Default</i>	<i>Unit</i>
100	10000	3000	msec

Software Overrun protection + side

K58

Software Overrun protection – side

K59

**Description**

This parameter sets the overrun protection on both CW and CCW sides. When the motor hits the overrun point it immediately stops. When the distance is set to 0 (default) the overrun setting is ignored.

<i>Min.</i>	<i>Max.</i>	<i>Default</i>	<i>Unit</i>
0	327670	0	*100 pulses(K58)
-32767	0	0	*100 pulses(K59)

**Deceleration**

Deceleration ratio

K44

**Description**

This parameter sets the deceleration based on acceleration (defined by the “A” command). The deceleration can be set as a percentage of acceleration. Note that the percentage set by this parameter will be applied to all deceleration in the CML program files. If you wish to set deceleration independent from acceleration you need to use CML commands. (please refer to the command section)

<i>Min.</i>	<i>Max.</i>	<i>Default</i>	<i>Unit</i>
10	500	100	%



## Manual Motion

### Manual Jog speed

K49

#### Description

This parameter sets the rotational speed for manual jog/feed.

Min.	Max.	Default	Unit
1	5000	10	100 pps

### Manual Jog distance

K50

#### Description

This parameter sets the travel distance for manual jog.

Min.	Max.	Default	Unit
1	100	10	100 pulses

## Gain Adjustment



### Position P Gain

K52


#### Description

This parameter sets the position loop proportional gain. There are two modes; constant and variable Position P gain. Enter an even value to apply constant P gain. Enter an odd value to automatically vary P gain depending on speed. Variable gain is typically useful when using a belt driven system.

With V2 firmware,  
the Reliance Cool  
Muscle now uses a  
modern control theory  
called H Infinity.

Please refer to Ap-  
pendix 9 to learn  
about tuning the  
new system.

K52-K54 are no  
longer used in V2  
or greater firmware



Variable P gain starts dropping at 600RPM. At 1200RPM, 1/5 the value set will be applied.




Min.	Max.	Default	Unit
0	512	depends on the motor type	1/256

## Speed P Gain

K53

### Description

This parameter sets the speed loop proportional gain. There are two modes; constant and variable Speed P gain. Enter an even value to apply constant P gain. Enter an odd value to automatically vary P gain depending on speed.



Variable P gain increases gradually until the motor reaches 600RPM. The set value is increased by 50 at 600RPM.

Min.	Max.	Default	Unit
0	512	depends on the motor type	1/256

## Speed I Gain

K54

### Description


This parameter sets the speed loop proportional gain. There are two modes; constant and variable Speed I gain. Enter an even value to apply constant P gain. Enter an odd value to automatically vary I gain depending on speed.

In the variable I gain mode, the relationship between the speed at which I gain will not be applied (Value 0) and the set I gain are as below.

$$\text{Speed (I gain becomes 0)} = \text{set I gain} \times 120$$



When the I gain is set to 5, the speed that I gain becomes 0 is 600RPM. If the I gain is set to 10, the speed that the I gain becomes 0 is 1200RPM.



Min.	Max.	Default	Unit
0	512	depends on the motor type	1/1024

## Pulse Type Cool Muscle

Pulse type

K36

### Description

This parameter sets Pulse Type Reliance Cool Muscle to either CW/CWW or Pulse/Direction. If you are using C Type Reliance Cool Muscle, this parameter allows you to assign Execute Bank 2 and 3 to rising and falling edges of input signals.

### P type Reliance Cool Muscle

#	Type
0(default)	CW/CCW
1	Step/Direction

### C type Reliance Cool Muscle

#	Type
2	changes the assignable input functions, Jog Manual CW and Jog Manual CCW, to Execute Bank 2 and 3. (K28,29,31,32)



When the motor is set to semi-closed loop, the Cool



Analogue Input functions are now part of the C Type motor interface.

The V type Reliance Cool Muscle has been discontinued.

## Analogue Input Control

### Analogue Interface Type

K38

#### Description

This parameter sets the motor to either Speed or position control when K64 is set to 9.

#### V type Reliance Cool Muscle

#	Type
0(default)	Speed
1	Position

### Analogue Speed Range

K40

This parameter sets the speed at 4.8V for Speed type analogue Reliance Cool Muscle. Increase an analogue input voltage from 2.6 to 4.8V to increase the speed in a CW direction. Decrease an analogue input voltage from 2.4V to 0.2V to increase the speed in a CCW direction. Note that an area between 2.4V and 2.6V is a dead zone within which no motion will occur.

Min.	Max.	Default	Unit
200	4000	3000	rpm

### Analogue Distance Range

K41

An increase in an analogue input voltage from 0V to 4.8V changes position in proportion to the input voltage. This parameter sets the maximum travel distance at 4.8V.



Example: Resolution 2000 (set by parameter 37)

Maximum movement range 90 degrees

$2000/(90/360 \text{ degrees})=500 \text{ pulses}$

Example : Resolution 2000 (set by parameter 37)

Pitch 5mm

Maximum travel distance 30mm

$30\text{mm}/5\text{mm}=6\text{rotations}$

$6 \text{ rotations} \times 2000 = 12000 \text{ pulses}$

<b>Min.</b>	<b>Max.</b>	<b>Default</b>	<b>Unit</b>
-32767	32767	2000	pulses

## Low Pass Filter

Voltage Filter Gain

K39

### Description

Cut-off frequency for Low Pass Filter for AD converter.

<b>Min.</b>	<b>Max.</b>	<b>Default</b>	<b>Unit</b>
0	1024	128	5(rad/sec)

(unit:  $5000[\text{times/sec}]/1024=5[\text{rad/sec}]$ )

## Push Mode

Push Current

K60

### Description

Current level applied when the motor is in push mode. The current level is set by % of peak current.

<b>Min.</b>	<b>Max.</b>	<b>Default</b>	<b>Unit</b>
10	70	50	%

**Push Time****K61****Description**


The time that the motor keeps pushing for when it is in push mode.

<b>Min.</b>	<b>Max.</b>	<b>Default</b>	<b>Unit</b>
10	3000	200	msec

**Creeping Speed****Creeping Speed****K51****Description**

Sets creeping speed. You can adjust the motors response time by changing the creeping speed. Setting creeping speed too high may cause the motor to vibrate.

<b>Min.</b>	<b>Max.</b>	<b>Default</b>	<b>Unit</b>
1	1000	10	100pps



Instead of gradually reaching the target speed or comes to a stop, the motor quickly reaches the target speed or stops, improving motor response time.



## Communication Speed

Baud Rate

K20

### Description

This parameter sets the baud rate that your PC and the Reliance Cool Muscle communicate at.

#	Rate
0(default)	38.4k
1	9.6k
2	19.2k
3	57.6k

## Semi-Closed/Full-Closed Loop Mode

Semi-Closed Loop Vector Angle

K21

### Description

You can set the Reliance Cool Muscle to either semi-closed or full-closed loop. In semi-closed loop mode, the Reliance Cool Muscle becomes open loop during holding, eliminating hunting problems. This parameter allows you to switch between full closed loop mode. When the Reliance Cool Muscle is set to semi-closed loop, you can use this parameter to set the vector angle at which the Reliance Cool Muscle returns to closed loop.

#	Rate
0(default)	full closed loop
1~36	# x 0.1 degree



## Tiriger Timing for Semi-Closed Loop Mode

K22

**Description**

This parameter lets you set a trigger timing for semi-closed loop. This trigger timing is a time delay between in-position signal and the moment that the Reliance Cool Muscle becomes open loop.

<i>Min.</i>	<i>Max.</i>	<i>Default</i>	<i>Unit</i>
10	1000	100	msec

**Motor Status Report Style**


## Polling/Event Driven Mode

K23

**Description**

This parameter lets you select a motor status report style; Polling or Event Driven.


#	<b>Style</b>
0	Polling
1	Running Status, Overflow, Overload, In Position, Circle Function, Pushing Torque
2	Input Status (represented as a HEX value)
4	Output Status
8	Status for Start, Stop, Enable, Disable, Pause



## SECTION 8

# PROGRAM MODE COMMANDS

This section contains CML commands for creating program banks along with examples. Commands for creating and executing programs banks, query commands are explained in Section 8.



## Motion Commands - define motion

Positions, Speeds, Accelerations and Timers need to be defined before motion is executed.

### Position Definition

#### Description

**P**

This parameter can define multiple positions. (Max. 25) The positions set by the P command is absolute. To make the value relative, add + after memory location. Once positions are defined you can call the stored position. If the value is larger than 1000000000 the motor will turn continuously CW as defined by speed setting. To turn the motor continuously in a CCW direction wet the speed to a negative value.

#### Examples:

P23=2500 (sets P23 to 2500)

P=1000000000 ( sets the motor to turn continuously)

P23+ (commands the motor to go relatively/incrementally the distance of 2500)

Memory#	Min.	Max.	Unit
25	0	999999999	pulses



## Speed Definition

**S****Description**

This parameter can define multiple speeds (Maximum 15). The speed unit can be set to either 100pps or 10pps by parameter K37.

**Examples:**

S10=20 (sets S10 to 2000pps)

<b>Memory#</b>	<b>Min.</b>	<b>Max.</b>	<b>Unit</b>
15	1	32767	100 pps or 10pps

## Acceleration Definition

**A****Description**

This parameter can define multiple accelerations (Maximum 8) The accelerations set by this command are absolute. This commands in combination with K44 also defines deceleration.

**Examples:**

A2=200 (sets A2 to 200Kpps<sup>2</sup>)

<b>Memory#</b>	<b>Min.</b>	<b>Max.</b>	<b>Unit</b>
8	1	32767	Kpps <sup>2</sup>

## Timer Definition

**T****Description**

This parameter can define multiple timers (Maximum 8)

**Examples:**

T1=1000 (sets T1 to 1000msec)

<b>Memory#</b>	<b>Min.</b>	<b>Max.</b>	<b>Unit</b>
8	1	32767	msec



## Program Commands - create programs

After parameters and motion values are defined, you can start creating motion programs. The command structure using the P, S, A, and T is as below.

S1,A1,P1 (go to P1 with the speed and acceleration defined by S1 and A1)

Motion commands are separated by a comma. The speed and acceleration that you want to apply to reach the target position must be placed before the P command.

The maximum steps that each motor can store is 100. Each command is counted as one step. For example, the above example is consisted of 3 steps.

### Program Bank

B

#### **Description:**

This command defines the beginning of a program bank. It also defines a program bank number. The maximum number of program banks that you can use is 16. Note that when you enter the B command, all the existing programs will be erased.

#### **Example:**

B1 (beginning of program bank 1)

S1,A1,P1 (Go to position 1 at the speed and acceleration defined by S1 and A1)

S2,A1,P3 (Go to position 3 at the speed and acceleration defined by S2 and A1)



## Call Program Bank

C



When the program bank called by the C command is completed, it goes to the next line of the line in which the C command was executed.

### Description

This command calls and executes specific program banks. The following program will execute Bank 1 and once Bank 2 is completed it will execute bank 3, and then come back to the first line of Bank 1, which will execute Bank 2.

### Example:

B1 (beginning of program bank 1)

C2 (call B2 and execute)

C3 (call B3 and execute)

B2 (beginning of program bank 2)

S3,A1,P1

B3 (beginning of program bank 3)

S2,A2,P3

## Jump to Program Bank

J

### Description

This command jumps to and executes specific program banks. The following program will execute Bank 1 and jump to and execute Bank 2. The program ends at the end of Bank 2. It will not go back to the program bank in which the jump command was originally executed.

B1 (beginning of program bank 1)

A1,S1,P3

J2 (jump to B2 and execute)

B2 (beginning of program bank 2)

x10(loop 10 times)

S3,A1,P1

P2

(It does not go back to B1)



## Input

I



Using the I and T0 commands you can create nesting within banks. Nesting can be used to select banks. The maximum nesting level is 10. A nesting example is described in the "applied CML program examples" section.

### Description

This command makes the motor perform specific actions or program banks based on the specified input status. This command takes the following form;

I#,True,False

### Example:

B1 (beginning of program bank 1)

I1,C3,C2 (If Input 1 is true execute bank 3, otherwise execute bank 2)

No Action

T0

### Description


This command is used with the I command.

### Example:

B1

I1,C2,T0(zero)

If Input 1 is true, the motor executes bank 2, otherwise it does nothing. When the I command line is followed by another command line, T0 moves the cursor to the next line and executes it. When bank 1 is completed, it goes back to line 1 in Bank 1. When Input 1 is true, it jumps to Bank 2 and executes it. Once B2 is completed, it goes back to line 2 in Bank 1.



**Set Output High****O****Set Output Low****F****Description**

The O command makes the specified output high/on and the F command turns the specified output low/off.

**Example:**

B1 (beginning of program bank 1)

S1,A2,P1,O1,P2,F1,P3

( this program commands the motor to go to P3 without stopping at P1 and P2. Output 1 goes high when the motor passes P1 and goes low when it passes P2).

**Push Mode****Q****Description**

The Q command takes the position value defined in a position memory location and commands the motor to perform a push mode.

A push mode is a special type of motion designed for applications typically performed by pneumatic cylinders. When moving to a final destination if the motor encounters resistance it may trigger an alarm. In push mode, a certain amount of resistance at the final destination is expected or anticipated and the motor does not produce an alarm. The motor based on the parameter settings will push into or apply pressure at the destination for a given time at a set current level or torque. You can make the motor push an object continuously by setting parameter K61 to 3001. Stop the motor from pushing by executing a new action using commands such as [, >, or ].

**Example:**


B1 (beginning of program bank 1)

S1,A1,P2,S2,Q3

(The motor performs a push mode between P2 and P3 at the



speed defined by S2 and for the time and at the current level defined by push mode parameters)



Shaded area represents a push mode

## Loop X

### Description

You can specify the number of times that you want a specific program bank to loop. A value of 0=infinite loops. Not specifying an X command results in a single execution of the program.

### Example:

B1,X3 (Loop B1 three times)

A1,S1,P1

P2

## P Command Without a Wait Y

### Description

When Reliance Cool Muscles motors are networked, a master motor waits for in-position signals from the slave motors before executing the next step in a program bank (with the P command). Using the Y command instead of the P command, you can make networked motors execute motion without waiting for other motors.

### Example:

B1

A1.1,S1.1,P1.1,A1.2,S1.2,A1.2,P1.2

P2.1,Y2.2 (Motor 2 execute the next line without waiting for in-position signal from Motor 1)



## Q Command Without a Wait

Z

### **Description**

When the Reliance Cool Muscles are networked, a master motor waits for in-position signals from slave motors before it executes the next step in a program bank (with the P command). Using the Z command instead of the Q command, you can make networked motors perform push mode action without waiting for other motors.

### **Example:**

B1

A1.1,S1.1,P1.1,A1.2,S1.2,A1.2,P1.2

P2.1,Q2.2 (Motor 2 performs push mode action without waiting for in-position signal from Motor 1)

## Comment

/

### **Description**

You can enter comments in the CML program files. Comments can be entered after a "/". Comments entered by "/" are not downloaded to the Reliance Cool Muscle. They are used for your reference in a text file.

## Execution Commands

### Execute Program Bank

[

### **Description**

Execute the specified program Bank.

[1 (executes Bank 1)]

**Execute Next Line**

&gt;

**Description**

Execute line by line in a program bank. This command is useful when debugging programs. Entering > will execute the first line in Bank 1. Enter > again to execute the next line. To execute a line in banks other than bank 1, you need to execute the bank program using the [command and stop. Then enter >.

**Execute Previous Line**

&lt;

**Description**

Execute previous line.

**Go Origin**

|

(it is a bar not an alphabet "I")

**Description**

Goes back to or searches for origin. Origin method is set by parameter 46.

| makes the motor do origin search.

|1 makes the motor go to position 0.

|2 sets the current position to 0.

**Pause**

]

**Description**

] pauses the motor. Enter [bank# to resume the program. Note that the program is resumed with the next executable line.

B1

S1,A1,P1

P2

P3

If the ] command is entered when the motor is moving from P1 to P2, the motor will stop somewhere inbetween the two points.



If [1 is entered to resume the program, the third command line will be executed, making the motor directly go to P3.

](CR)] pauses the motor and resets the program to its first command line.

Stop After Completing Motion

}

**Description**

Stops after completing current motion.

Motor Free

)

**Description**

De-energizes the motor windings, leaving the rotor free to rotate. The motor's circuit board and encoder remain active.

Enable Motor

(

**Description**

Use this command to enable the motor in a free state.

Save to EEPROM

\$

**Description**

Saves CML Program Banks and P, S, A, and T values to the EEPROM on the Reliance Cool Muscle. Changes to K parameter values are automatically saved when changed.

B1

S1,A1,P1

P1=1000

S1=100

A1=100

\$



## Query

**Description**

Shows motor information.

?#	Content	
?0-16	bank no.	
?70	input status (D0~D7)	Displays Inputs = high 1=input 1 2=input 2 4=input 3 8=input 4 Multiple inputs: add numbers ie. input 1 and 3 are high=5 $1 + 4 = 5$ If the total is more than 10 A=input 2 and 4 B=input 1,2 and 4 C=input 3 and 4 D=input 1,3 and 4 E=input 2,3, and 4 F=input 1,2,3 and 4
?71	input status (D8~D15) reserved for expansion	
?72	output status (D0~D7)	Displays Outputs = high 1=Output 1 2=Output 2
?73	analogue input value CH1	
?74	analogue input value CH2	
?75	counter value CH1	
?76	counter value CH2	
?90	parameter list for user	
?91	position definition list	
?92	speed definition list	
?93	acceleration definition list	
?94	timer definition list	
?95	position error	
?96	current position	
?97	current speed	
?99	Motor status message	0: Running 1: overflow 2: overspeed/regenerative voltage 4: overload 8: Inposition



## Basic CML Program Examples

Most machine movement is repetitive and makes use of only a few positions, speeds, accelerations and timers. This type of information makes up part of the header of a CML file.


The following motion definitions are used for the examples in this section.

```
P1=20000  
P2=72000  
P3=120000  
P4=500000  
S1=5500  
S2=7000  
S3=8500  
S4=10000  
A1=200  
A2=500  
A3=800
```

### Basic Point to Point motion

```
B1  
A1,S1,P1  
S2,P2  
S3,P3
```

This creates the motion below.



Starting at the origin position, the motor moves from point to



point, stopping and starting at each point with equal acceleration reaching different speeds.

Notice that the same acceleration is applied to P1, P2 and P3. You can leave out S and A when the same Speed or Acceleration are applied to different target positions, saving the number of steps.

### **Continuous Point to Point motion with different speeds**

B2

A1,S1,P1,S2,P2,S3,P3

By combining the same motion commands on one line, the following motion is created.




As compared to program bank B1, B2 has no stops in its motion between Origin and P3. Speed was changed at each point and the acceleration and deceleration remained equal throughout.

### **Continuous Point to Point motion with different speeds and accelerations**

B3

A1,S1,P1,A2,S2,P2,A3,S4,P3





Including acceleration changes at each point and increasing the speed prior to the last point may create motion similar to the chart below.

### Point to Point motion with different deceleration


The deceleration rate is always equal to the last acceleration rate specified taking into account the value of parameter K44.

This can be modified in two ways. The first way is to set the Acceleration/Deceleration Ratio parameter. This results in a set ratio for every motion. The second way is to place multiple commands within a single line of CML, it is possible to specify both an acceleration and a deceleration. Suppose the final destination is P2 and a quick acceleration followed by a slow deceleration is required.

B5

A1,S1,P1,A2,P2

Resulting in the following motion.




Keeping the speed across two points equal, and changing the acceleration value will give you a different deceleration to reach the final destination.

### Push Mode

Using the Q command makes the motor perform a push mode. A push mode mimics a typical pneumatic cylinder and would keep pushing for a given time and at a set current level when the motor finds a resistance such as stopper or bumper. Parameters K60 and K61 also need to be set to values best fitting your requirements.




B6  
A1,S3,P2,S1,Q3



## Networking Reliance Cool Muscle Motors

Reliance Cool Muscle serial networks are arranged for daisy chain communication. Commands are passed from device to device along the network. ID's are assigned automatically at power up. The master motor has bank programs to control all networked motors. Motion definitions (P, S, A, T) are stored in each motor. Only the master motor will respond to a [ execution command.



### Defining Motion for multiple motors

When programing multiple motors, the motor ID needs to be specified at the beginning of a program. Once a motor ID is specified, it assumes that motor ID is set for the previously specified motor ID until another motor ID is specified.



```
.1(Motor ID1/Master)
P1=1000
P2=2000
S1=200
A1=100
A2=300
P1.2=2000 (Motor ID2, alternative syntax)
P2=2500
S1=200
S2=400
A1=100
A2=300
.3(Motor ID3)
P1=20000
P2=24000
S1=300
S2=400
A1=50
A2=300
$(Save)
```


or you can define motion values in the following format.

```
P1.1=1000 (Set Motor 1 position 1 to 1000 pulses)
P1.2=2000 (Set Motor 2 position 1 to 2000 pulses)
P1.3=2000 (Set Motor 3 position 1 to 2000 pulses)
S1.2=400 (Set Motor 2 speed 1 to 40kpps)
```

### **How to create network programs**

Programs for a network should be designed to have one motor as a master. A master motor contains program banks that control the whole network.

***Basic network program example 1:***  
B1(Program Bank 1)  
A1.1, S1.1,P1.1,A1.2,S1.2,P1.2  
P2.1,P2.2



**Line 1**


Defines first motion for motor 1 (Master) and motor 2. Writing commands for both motors in the same line makes both motors start at the same time. Motor 1 moves to P1.1 at the speed and acceleration defined by S1.1 and A.1 and Motor 2 moves to P1.2, at the speed and acceleration defined by S1.2 and A1.2.

**Line 2**

After both motors have reached the first target positions (P1.1 and P1.2) they execute the motion defined by line 2. Motor 1 moves to P2.1 at the same speed and acceleration as in line 1. Motor 2 moves to P2.2 at the same speed used in line 2.

**Line 3**


After both motors have reached the target positions, Motor 1 moves to P3.1.



## SECTION 9

# Dynamic Mode Commands

In this section, motion commands, execution commands for dynamic mode are introduced.



## Motion Commands

Dynamic Commands cause immediate action. This mode is typically used for debugging and non-repetitive movements.

Position	P
----------	---

**Description**

Set position.

P=10000

Unit: Pulses

Speed	S
-------	---

**Description**

Set Speed.

S=250

Unit: 100pps or 10pps set by parameter K37.



## Acceleration

A

**Description**

Set Acceleration.

A=250

Unit: Kpps<sup>2</sup>

## Execution Commands

### PTP Movement

Λ

**Description**

Directly type in commands to cause immediate PTP movement.

P=1000000

S=2000

A=200

^

### CP Movement

~

**Description**

This command makes the motor to move between specified points at the maximum speed with maximum acceleration.

The values are incremental.

P=2

~

P=5

~

P=10

~



## Go Origin

(it is a bar not an alphabet "I")

### **Description**

Goes back to or searches for origin. Origin method is set by parameter 46.

| makes the motor do origin search

|1 makes the motor go to position 0.

|2 sets the current position to 0.

## Pause

]

### **Description**

] pauses the motor. Enter [bank# to resume the program. Note that the program is resumed with the next executable line.

B1

S1,A1,P1

P2

P3

If the ] command is entered when the motor is moving from P1 to P2, the motor will stop somewhere in between the two points. If [1 is entered to resume the program, third command line will be executed, making the motor directly go to P3.

](CR)] pauses the motor and resets the program to its first command line.



Motor Free

)

**Description**

De-energizes the motor windings, leaving the rotor free.




When executing this command after an alarm, please first send a ] to stop any program execution. Enabling the motor after an alarm or after a ) command issued during operation may result in immediate resumption of motion.

Enable Motor

(

**Description**

Energizes the motor windings and resets any error states after an alarm.




## SECTION 10

# Applied CML Program Examples

This section shows you applied CML program examples using the parameters and commands.

## Example 1: Setting I/Os-Pulse type



### Parameters

K25=1122 (set time delay between quick and slow response to 0.1sec, 0.1 sec, 0.2sec, 0.2sec for input 4,3,2,1)

K26=1111 (Set input logic for port 4,3,2,1 to high in true)

K27=0052 (Set QTV funcitons)

K31=0210 (Set SR functions)

K32=0200 (Set SF functions)

K33=00 (set output logic for port 2,1 to high in true)

K34=21 (set output functions)

### Input

	QTV	SR	SF
Input 1	Origin Signal		
Input 2	Index Signal	Alarm Reset	
Input 3		Motor Free	Enable Motor

### Output


Output 1	Inposition
Output 2	Alarm



### Motion descriptions

This example shows how you can assign multiple functions to a single input. K25 sets the time delay between quick and slow response signals. Origin is searched or defined by an origin switch. When the target voltage level on Input 2 is high, it switches output 2 from In-position signal to index signal. This is how you can differentiate In-position from On-origin signals.

#### Example 2: Search origin using a bumper - Pulse type



### Parameters

K25=1122 (set time delay between quick and slow response to 0.1sec, 0.1 sec, 0.2sec, 0.2sec for input 4,3,2,1)

K26=1111 (Set input logic for port 4,3,2,1 to high in true)

K27=0050 (Set QTVfuncitons)

K28=0007 (Set QR funciton)

K31=0210 (Set SR functions)

K32=0200 (Set SF functions)

K33=11 (set output logic for port 2,1 to high in true)

K34=21 (set output functions)

K46=0 (find origin by stopper/bumper)

K42=15 (set origin search speed )

K43=150 (set origin search acceleration)

K45=0 (directin of origin set to CW)

K47=30 (current level when pushing a bumper)

### Input

	QR	QTV	SR	SF
Input 1	Origin Search	Origin Signal		
Input 2		Index Signal	Alarm Reset	
Input 3			Motor Free	Enable Motor




### Output

Output 1	Inposition
Output 2	Alarm

### **Motion descriptions**

The previous example showed how to search for origin using an origin sensor. As an alternative, you can use a bumper or stopper to make the motor search for an origin. The motor starts to search for an origin when input 1 goes high. (at the rising edge of a quick response signal). The motor turns in a CW direction at the speed and with the acceleration set by parameter 42 and 43. The motor determines that it has found or reached an origin when its current reaches 30% of its peak current.

### Example 3: Manual Feed and Jog



### **Parameters**

K25=1122 (set time delay between quick and slow response to 0.1sec, 0.1 sec, 0.2sec, 0.2sec for input 4,3,2,1)

K26=1111 (set input logic for port 4,3,2,1 to high in true)

K28=0198 (set quick rising funcitons) K30=0043 (set STV functions)

K30=0043 (set STV functions)

K33=00 (set output logic for port 2,1 to high in true)

K34=21 (set output functions)

K46=1 (find origin by switch)

K42=15 (set speed at which the motor searches or goes to origin)

K43=150 (set acceleration with which the motor searches for or goes to origin)

K45=0 (direction of origin set to CW)



K49=15 (set manual speed)

K50=20 (set manual jog pulses)

#### Input

	QR	STV
Input 1	Manual Jog CW	Manual Feed CW
Input 2	Manual Jog CCW	Manual Feed CCW
Input 3	Alarm Reset	


#### Output

Output 1	Inposition
Output 2	Alarm

#### **Motion descriptions**

This examples shows manual jog and manual feed. The travel distance for the manual jog is set to 20 pulses by parameter 50. The manual speed is set to 1500 pps by parameter 49. The acceleration for manual operation is the same as the acceleration of go-origin. A short signal (less than 0.2sec) will trigger manual jog which turns the motor 20 pulses. If a signal longer than 0.2 is sent, the motor turns continuously for the duration of the signal. In this case, manual jog and manual feed are merged.

Example 4: Electric orientation with continuous PTP program



#### **Parameters**

K25=1122 (set time delay between quick and slow response to 0.1sec, 0.1 sec, 0.2sec, 0.2sec for input 4,3,2,1)

K26=1111 (set input logic for port 4,3,2,1 to high in true)



K27=0002 (set STV functions)  
K28=0167 (set QR functions)  
K33=00 (set output logic for port 2,1 to high in true)  
K34=21 (set output functions)  
K46=1 (find origin by switch)  
K42=15 (set speed at which the motor searches or goes to origin)  
K43=150 (set acceleration with which the motor searches for or goes to origin)  
K45=0 (direction of origin set to CW)  
K48=100 (set mechanical and electric origin offset to 10000 pulses)

**Input**

	QR	STV
Input 1	Origin Search	Origin Signal
Input 2	Execute 1	
Input 3	Pause/Alarm Reset	

**Output**

Output 1	Inposition
Output 2	General Use

***Motion program***

B1

S1,A1,P1,S2,P2,S3,P3

***Motion descriptions***


By setting the offset distance between the mechanical and electric origins, you can make the motor automatically move to the electric origin after it finds or goes to a mechanical origin. In this example, the electric origin is set to 10000 pulses away from the mechanical origin.

A program in Bank 1 is executed at the target voltage level of a quick response signal on Input 1. Output 2 goes high when the motor passes P1 and stays high until it passes P2. This type



of signal is different from in-position signals and can be used to signal your controller or other motors to perform tasks.

### Example 5: Pause



#### Parameters

K25=1122 (set time delay between quick and slow response to 0.1sec, 0.1 sec, 0.2sec, 0.2sec for input 4,3,2,1)

K26=1111 (set input logic for port 4,3,2,1 to high in true)

K27=0002 (set QTV level functions)

K28=0761 (set QR functions)

K33=00 (set output logic for port 2,1 to high in true)

K34=21 (set output functions)

K46=1 (find origin by switch)

K42=15 (set speed at which the motor searches or goes to origin)

K43=150 (set acceleration with which the motor searches for or goes to origin)

K45=0 (direction of origin set to CW)

#### Input

	QR	QTV
Input 1	Origin Search	Origin Signal
Input 2	Execute Bank1	
Input 3	Alarm Reset/Pause	

#### Output

Output 1	Inposition
Output 2	Alarm


**Motion program**

B1

S1,A1,P1

**Motion descriptions**

This example shows how you can pause a program. During the execution of Bank 1, the motor is paused somewhere in between the origin and P1. By making Input 2 high, the paused program will be resumed.

**Example 6: Bank Select using nesting****Parameters**

K25=1122 (set time delay between quick and slow response to 0.1sec, 0.1 sec, 0.2sec, 0.2sec for input 4,3,2,1)

K26=1111 (set input logic for port 4,3,2,1 to high in true)

K27=0112 (set QTV functions)

K28=2667 (set QR functions)

K29=2000 (set QF level functions)

K33=00 (set output logic for port 2,1 to high in true)

K34=21 (set output functions)

K46=1 (find origin by switch)

K42=15 (set speed at which the motor searches or goes to origin)

K43=150 (set acceleration with which the motor searches for or goes to origin)

K45=0 (direction of origin set to CW)

**Input**

	QR	STV	QF
Input 1	Origin Search	Origin Signal	
Input 2	Execute Bank 1	General Use	
Input 3	Execute Bank 1	General Use	
Input 4	Motor Free		Enable Motor

**Output**

Output 1	Inposition
Output 2	Alarm

***Motion program***

B1  
T1  
I2,C2,C3  
B2  
I3,C4,T0  
S2,A1,P3  
B3  
I3,C5,T0  
S1,A3,P2  
B4  
S3,A1,P4  
B5  
S1,A1,P1

***Motion descriptions***

You can select a bank via digital Inputs by using a nesting technique. The above motion program shows how you can program in such a way as to allow for bank select using two input ports. When both Input 2 and Input 3 are low Bank 1 will be executed. The motor will go to P1 at the speed and acceleration defined by S1 and A1. When Input 2 is high and input 3 is low, it jumps to Bank 2 and executes the program. When Input 2 is low and Input 3 is high, it jumps to Bank 3 and executes it. When both inputs are high, then it jumps to Bank 4 and executes the program.




	Input 2	Input 3
Bank 1	Low	Low
Bank 2	High	Low
Bank 3	Low	High
Bank 4	High	Hlgh



# Appendix1


## Reliance Cool Muscle Dimensions

CM1-□-17L30



Model	L1	L2	L3
CM1-x-17L30	1.968(50)	3.74±0.039 (95±1)	0.708±0.0196 (18±0.5)
CM1-x-17S30	1.338(34)	3.326±0.039 (34.5±1)	0.944±0.0196 (24±0.5)

CM1-□-23L20



Model	L1	L2
CM1-x-23L20	2.992(76)	4.964±0.039 (126.1±1)
CM1-x-23S30	1.653(42)	3.625±0.039 (92.1±1)



## Reliance Cool Muscle Specifications

### CM1-□-17□30

Specification	CM1- X -17L30	CM1- X -17S30
Motor Output Power	18W	18W
Max. Speed	3000rpm	3000rpm
Rated Continuous Torque Nm(oz.in)	0.38(53.8)	0.082(11.61)
Rated Peak Torque Kgfcm Nm(oz.in)	0.54(76.4)	0.117(16.56)
Load Inertia Allowance Kg.cm.s <sup>2</sup> (ozf.in.s <sup>2</sup> )	$7.6 \times 10^{-4}$ ( $1.08 \times 10^{-2}$ ) Depending on the load inertia, servo gain needs to be adjusted. Within the above range: adjustable by parameters Outside the range: please contact us.	$3.8 \times 10^{-4}$ ( $5.39 \times 10^{-3}$ )
Motor Inertia Kg.cm.s <sup>2</sup> (ozf.in.s <sup>2</sup> )	$7.6 \times 10^{-5}$ ( $1.08 \times 10^{-3}$ )	$3.8 \times 10^{-5}$ ( $5.39 \times 10^{-4}$ )
Encoder	Incremental Magnetic Encoder (50000 pulses/rotation)	
Control Method	Closed Loop Vector Control	
Input Supply Voltage	DC24V±10%	
Input Supply Current Rated (Continous/Rated peak)	1.2A/1.8A	1.2A/1.8A
Resolution Pulse Rotation (pulse/rotation)	200,400,500,1000,2000,2500,5000,10000,25000,50000 Set by parameter	
Environmental Conditions Operation/Storage	between 0 °C and 40°C/between -20°C and +60°C	
Operating Humidity	Less than 90%RH	
Impact/Vibration	Less than 10G/Less than 1G	

### CM1-□-23□30

Specification	CM1- X -23L20	CM1- X -23S30
Motor Output Power	30W	45W
Max. Speed	2000rpm	3000rpm
Rated Continuous TorqueKgfcm(Nm)	0.87(123.2)	0.29(41.06)
Rated Peak Torque Kgfcm(Nm)	1.24(175.6)	0.46(65.14)
Load Inertia Allowance Kg.cm.s <sup>2</sup> (ozf.in.s <sup>2</sup> )	$4.61 \times 10^{-3}$ ( $6.5 \times 10^{-2}$ ) Depending on the load inertia, servo gain needs to be adjusted. Within the above range: adjustable by parameters Outside the range: please contact us.	$1.4 \times 10^{-3}$ ( $1.9 \times 10^{-2}$ )
Motor Inertia Kg.cm.s <sup>2</sup> (ozf.in.s <sup>2</sup> )	$4.61 \times 10^{-4}$ ( $6.5 \times 10^{-3}$ )	$1.4 \times 10^{-4}$ ( $1.9 \times 10^{-3}$ )
Encoder	Incremental Magnetic Encoder (50000 pulses/rotation)	
Control Method	Closed Loop Vector Control	
Input Supply Voltage	DC24V±10%	
Input Supply Current Rated (Continous/Rated peak)	2.6A/3.4A	3.9A/5.1A
Resolution Pulse Rotation (pulse/rotation)	200,400,500,1000,2000,2500,5000,10000,25000,50000 Set by parameter	
Environmental Conditions Operation/Storage	between 0 °C and 40°C/between -20°C and +60°C	
Operating Humidity	Less than 90%RH	
Impact/Vibration	Less than 10G/Less than 1G	



## Pin Layout

PIN #	Type	Function	Default			
			CW/CCW	Step/Dir	Analogue	Computer
1	+24VDC IN	Power				
2	GROUND 1					
3	INPUT 2-		CCW -	Direction -		
4	OUTPUT 2+	Digital Out Analogue Out Serial TX				Serial Port2
5	OUTPUT 1+	Digital Out Analogue Out Serial TX				Serial Port1
6	INPUT 4+	Digital Input, Analogue Input				
7	INPUT 3+	Digital Input			V +	
8	INPUT 1-		CW-	Step -		
9	INPUT 2+	Digital Input,Pulse Counter,Serial RX	CCW +	Direction +		Serial Port2
10	INPUT 1+	Digital Input,Pulse Counter,Serial RX	CW +	Step +		Serial Port1
11	GROUND 2				V -	
12	+5VDC OUT	5V Out				

## Input/Output Signal

### P type

Pulse	CW/CCW	STEP/DIRECTION
Input Signal Pulse Input	CW/CCW Pulse Maximum Frequency: 500Kpps Minimum Pulse Width: 0.8μsec Voltage Level H >+3.0V (+24VMAX. 7mA-15mA) Voltage Level L <+0.8V	Step Pulse Maximum Frequency: 500Kpps Minimum Pulse Width: 0.8μsec Voltage Level H >+3.0V (+24VMAX. 7mA-15mA) Voltage Level L <+0.8V

**V type - These functions have been included into the C type motor.**

Analog	
Input Signal Variable Voltage Input	Speed control setting Increase from 2.6 V to 4.8DC, increases speed CW. Decrease from 2.4V to 0VDC, increases speed CCW. Use OP AMP for max. resolution.
	Position control setting Travel distance is proportionate to the input voltage. Set the max. distance by parameter.


### C type

Computer Control Interface	
Input Signal Control	Via supplied Cable Voltage Level H >+3.0V (+24VMax. 7mA-15mA), Voltage Level L <+0.8V



## Connection Diagram

Controller Example



# Appendix 2

## Parameters



Parameter #	Descriptions	Min.	Max.	Default	Unit	Details	Applicable Types
K20	Baud Rate	0	5	0	K	Sets the Baud Rate 0: 38.4 1: 9.6 2: 19.2 3: 57.6	
K21	Full/Semi Closed	0	36	0	0.1 degrees	Sets the motor to either Full or Semi Closed mode. When set to other than 0, it sets the motor to semi closed mode and the vector angle at which the motor returns to full closed mode. 0: full closed loop 1-36: vector angle	
K22	Time delay for Semi-Closed Mode	10	1000	10	msec	Sets the time delay until the motor goes into an open mode after in-position signal.	
K23	Motor Status	0	1	0		Sets the motor to Polling or Event Driven 0: Polling 1: Event Driven	
K24	Timed Trigger Interval	10	32767	1000	pulses	Sets the distance interval for the timed trigger.	
K25	Time delay for Slow Response Signal	1111	9999	3333	0.1sec	Sets time delay for slow response signal. Input order is P,V,C Pin4, Pin3, Pin2, Pin1.	P,V,C
K26	Input logic	0000	1111	0000		Sets Input Logic. 0:Ture in Low 1:Ture in High	P,V,C
K27	Input function at target voltage level (Quick Response Signal)	0000	5555	0000		Assigns a function at the target voltage level . Input order is Pin4, Pin3, Pin2, Pin1. 0:No Action 1:General Use 2:Origin Sensor 3:Manual Feed CW 4:Manual Feed CCW 5:Output Index signal instead of Inposition Signal	P,V,C



Parameter #	Descriptions	Min.	Max.	Default	Unit	Details	Applicable Types
K28	Input function at the rising edge of Quick Response Signal	0000	9999	0100		Assigns a function at the falling edge of quick response signal. Input order is Pin4, Pin3, Pin2, Pin1. 0:No Action 1:Alarm reset/Pause 2:Motor Free 3:Reset Counter 4:Execute Next Step 5:Execute Previous Step 6:Execute Bank 1 7:Go Origin 8:Manual Jog CW (Execute Bank 2 when K36=2) 9:Manual Jog CCW(Execute Bank 3 when K36=2)	
K29	Input function at the falling edge of Quick Response Signal	0000	9999	0000		Assigns a function at the falling edge of quick response signal. Input order is Pin4, Pin3, Pin2, Pin1. 0:No Action 1:Alarm reset/Pause 2:Enable Motor 3:Reset Counter 4:Execute Next Step 5:Execute Previous Step 6:Execute Bank 1 7:Go Origin 8:Manual Jog CW (Execute Bank 2 when K36=2) 9:Manual Jog CCW(Execute Bank 3 when K36=2)	P,V,C
K30	Input function at target voltage level (Slow Response Signal)	0000	9999	0000		Assigns a function to the target voltage level . Input order is Pin4, Pin3, Pin2, Pin1. 0:No Action 1:General Use 2:Origin Sensor 3:Manual Feed CW 4:Manual Feed CCW 5:Output Index signal instead of Inposition Signal	P,V,C



Parameter #	Descriptions	Min.	Max.	Default	Unit	Details	Applicable Types
K31	Input function at the rising edge of Slow Response Signal	0000	5555	0200		Assigns a function to the rising edge of slow response signal. Input order is Pin4, Pin3, Pin2, Pin1. 0:No Action 1:Alarm reset/Pause 2:Motor Free 3:Reset Counter 4:Execute Next Step 5:Execute Previous Step 6:Execute Bank 1 7:Go Origin 8:Manual Jog CW (Execute Bank 2 when K36=2) 9:Manual Jog CCW(Execute Bank 3 when K36=2)	P,V,C
K32	Input function at the falling edge of Slow Response Signal	0000	5555	0300		Assigns a function to the falling edge of slow response signal. Input order is Pin4, Pin3, Pin2, Pin1. 0:No Action 1:Alarm reset/Pause 2:Enable Motor 3:Reset Counter 4:Execute Next Step 5:Execute Previous Step 6:Execute Bank 1 7:Go Origin 8:Manual Jog CW (Execute Bank 2 when K36=2) 9:Manual Jog CCW(Execute Bank 3 when K36=2)	P,V,C
K33	Output Logic	00	11	00		Sets Output Logic. 0:Normally Open 1:Normally Closed	P,V,C
K34	Output Function	00	66	21		Assigns output function. 0:Command (when using in a command mode you need to set to O) 1:Inposition 2:Alarm 3:General Use1 4:General USs2 5:Analog Output 6:Output Inposition Signal in Merge Mode.	P,V,C



Parameter #	Descriptions	Min.	Max.	Default	Unit	Details	Applicable Types
K35	Analog Output Function	00	99	31		When Parameter 34 is set to Analog Output (5), choose one of the analog output types. Analog Wave can be monitored in actual size or magnified by 8times. 0: Target position 1: Target position magnified by 8 2: Current Position 3: Current Position magnified by 8 4: Position Error 5: Position Error magnified by 8 6: Current Velocity 7: Current Velocity magnified by 8 8: Current Torque 9: Current Torque magnified by 8	P,V,C
K36	Pulse Interface	0	1	1		Set Pulse type to either CW/CCW or Step/Direction. 0:CW/CCW 1:Step/Direction C type Cool Muscle 2:enables bank 2 and 3 execution	P
K37	Resolution and Speed unit	00	30	4		Sets resolution and speed unit on the motor. To set the speed unit to 100pps, use one of the resoration settings. 0:200, 1:400, 2:500, 3:1000, 4:2000, 5:2500, 6:5000, 7:10000, 8:25000, 9:Reserved , 10:50000  To set the speed unit to 10pps, use one of the resoration settings. 20:200, 21:400, 22:500, 23:1000, 24:2000, 25:2500, 26:5000, 27:10000, 28:25000, 29:Reserved , 30: 50000	P,V,C
K38	Analog Interface(V Type)	0	1	0		Sets V type motor to be either Speed Control or Position Control. 0:Speed Control 1:Position Control	V,C



Parameter #	Descriptions	Min.	Max.	Default	Unit	Details	Applicable Types
K39	Voltage Filter Gain	0	1028	128	5[rad/sec]	Sets cut-off frequency for voltage Low Pass filter.	V
K40	Max. speed for V Type	200	3000	2000	rpm	Sets the max. speed for V type Cool Muscle. Increasing from 2.6V to 4.8V increases speed in a CW direction. At 4.8V the motor reaches the Max. CW speed set by this parameter. Decreasing from 2.4V to 0.2V increases speed. At 0.2V it reaches the max. CCW speed.	V
K41	Travel Range for V Type	-32767	32767	2000	pulses	Sets the Max . travel for V type Cool Muscle. Increasing Voltage from 0.2V to 4.8V changes position in proportion to Input voltage.	V
K42	Go Origin Speed	1	5000	10	100pps	Sets Go Origin speed	P,V,C
K43	Go Origin/Manual feed Acceleration	1	5000	100	kpps <sup>2</sup>	Sets acceleration for Go Origin and Manual Feed.	P,V,C
K44	Deceration Ratio	10	500	100	%	Sets Deceleration ratio in relation to Acceleration. ie. K44=30 Deceleration is set to 30% of Acceleration.	C
K45	Origin Direction	0	1	1		Sets origin direction 0:CW 1:CCW	P,V,C
K46	Origin Search Method	0	1	0		Sets origin search method 0:Stopper 1:Stopper(start origin search when powered on) 2:Origin Switch 3:Origin Switch (start origin search when powered on)	P,V,C
K47	Origin Stopper Voltage Level	10	100	30	%	When K46 is set to 1 or 2(Origin search by Stopper), you need to set the voltage level at which the motor determines that it has reached the origin. It is set by a percentage of the peak current.	P,V,C



Parameter #	Descriptions	Min.	Max.	Default	Unit	Details	Applicable Types
K48	Offset distance between machine origin and mechanical origin	-32767	32767	0	100 pulses	Sets offset distance between mechanical and electrical origins. When the offset distance is set, it will automatically move to the electrical origin after reaching mechanical origin. When the parameter is set to 0, mechanical and electrical origin are the same. Speed moving from mechanical and electrical origins is the same as go origin speed set by parameter 42.	P,V,C
K49	Manual feed speed	1	5000	10	100pps	Sets manual feed speed.	P,V,C
K50	Manual Jog travel distance	1	100	10	pulses	Sets manual jog travel distance.	P,V,C
K51	Creeping Speed	1	1000	10	100pps	Sets creeping speed	P,V,C
K52	Position P gain	0	300	50	1/256	Sets Position P gain.	P,V,C
K53	Velocity P gain	0	300	250	1/256	Sets Velocity P gain.	P,V,C
K54	Velocity I gain	0	500	2	1/1024	Sets Velocity I gain.	P,V,C
K55	Inposition tolerance	1	100	5	pulses	Sets Inposition tolerance . The motor determines that it has reached the target position, when it gets within the set Inposition tolerance.	P,V,C
K56	Overflow Alarm Level	1	32767	50	K pulses	Set Overflow Alarm Level. When position error is larger than the value set by this parameter, the motor sends out an alarm.	P,V,C
K57	Overload Alarm Time Delay	100	10000	3000	msec	Time delay between overload is detected and alram is sent out.	P,V,C
K58	Software Limit(+)	0	32767	0	100 pulses	Sets limits on the +(CW )side. When set to 0, it ignores software limit.	C
K59	Software Limit(-)	-32767	0	0	100 pulses	Sets limits on the +(CCW )side. When set to 0, it ignores software limit.	C
K60	Push Mode Current Level	10	70	30	%	Sets the current level for Push mode. The motor keeps pushing a stopper/wall at the set current for the duration set by parameter 61.	C
K61	Push time	10	3000	200	msec	Sets the duration which the motor pushes in push mode.	C

see Appendix 9 for information on K64 (Analog Input function)

# Appendix 3

## Program Mode - Motion Commands

Command	Function	Memory #	Format	Unit	Description	Examples
P	Position	25	P\Memory#=Value or P\Memory #	pulses	Value holder for absolute positions. Used in CML programs in EEPROM. If P is given a value over 1000000000, the motor spins continuously CW . To turn the motor in a CCW set the speed value negative.	P23=2903274 Sets P23 to 2903274
S	Speed	16	S\Memory#=Value or S\Memory #	100pps	Value holder for speed. Used in CML programs in EEPROM.	S13=20 Sets S13 to 2Kpps
A	Acceleration	8	AMemory#=Value or AMemory #	1Kpps <sup>2</sup>	Value holder for Acceleration. Used in CML programs in EEPROM	A13=200 Set A13 to 200Kpps <sup>2</sup>
T	Timer	8	T\Memory#=Value or T\Memory #	msec	Set Timer	T1=1000 Set T1 to 1000msec.
B	Program Bank	16	B Bank#		B# specifies the Bank program #. This signifies the beginning of a program bank with a CML program file.	T1 After reaching P1, the motor waits for the time period defined by T1.
C	Call Bank		C Program bank#		Calls a specified program bank and executes.	B1 S1,A1,P1 S2,A2,P3 C2(calls B2 and executes)





Command	Function	Memory #	Format	Description	Examples
J	Jump		J Bank#	Jumps and execute the specified program bank.	B1,A1,S1,P1 J2 B2 S2,A2,P3
O	Output High	2	O Output #	Sets the output specified high/on.	S1,P1 O1 F1
F	Output Low	2	F Output#	Sets the output specified low/off.	S1,P1 F1
I	Input	4	I Input#,True, False	The I command monitors a specified input and will execute an action based on the input state.	I1,C3,C2 If input1 is on execute bank3, otherwise execute bank2.
Q	Push Mode	25	Q Position#	The Q command is a replacement for the P command when a push mode movement is required.	B1 A1,S1,Q1
X	Loop		X#	Specify the number of loop for a specified program bank.	B1 X2 A1,S1,P1 Loops B1 twice
Y	P without a wait	25	Y Position#	When networking the motors, use the Y command instead of P to make motors execute motion individually.	B1 S1,P1,1,S1,2,P1,2 P2,1,Y2,2 Motor 2 executes line 2 without waiting for motor 1 to complete motion.
Z	Q without a wait	25	Z Position#	When networking the motors, use the Z command instead of Q to make motors execute push mode movement individually.	B1 S1,P1,1,S1,2,P1,2 P2,1,Q2,2 Motor 2 executes push mode without waiting for motor 1 to complete motion.
T0	No action		I1,C1,T0	Use with the I command. It is a place holder. T0(ZERO)	3,T0,C2 If Input 3 is on the motor does not do anything. If Input 3 is off it executes bank2.
/	Comment		/comment	/begins a comment in a CML program file. All comments are stripped when a file is downloaded into a motor.	B1/move to the first hole.



## Program Mode - Execution Commands

Command	Function	Format	Description	Examples
[	Execute Bank program	[ bank#	Sets the output specified high/on.	[1 Executes bank program1
>	Execute next line	>	Executes the next line in the program bank.	> Executes the first step in bank 1
<	Execute previous line	<	Executes the previous line in the program bank.	< Executes the previous line in the current bank program.
(bar)	Go Origin	((bar) [1 [2]	:Make the motor go origin  :1:Make the motor go to position0  2:Sets the current position to 0	
]	Immediate Stop/Pause	] []	Pauses the motor . To resume the program enter [bank#]. Pauses the motor and rests the program bank to its first command line.	
}	Stop after current motion	}	Stop the motor when it completes current motion.	
)	Motor Free	)	Turns the motor into a free state	
(	Enable Motor	(	Enables the motor in a free state.	



## Other commands

### Dynamic Mode - Motion Commands

Command	Function	Format	Unit	Description	Examples
P	Position	P= position	pulses	Define the position in dynamic mode.	P=2903274
S	Speed	S=Speed	100ppps	Define the speed in dynamic mode.	S=20
A	Acceleration	A=Acceleration	1Kpps <sup>2</sup>	Define the acceleration in dynamic mode.	A=200

### Dynamic Mode - Execution Commands

Command	Function	Format	Description	Examples
^	Execute dynamic commands	^	This command executes dynamic commands in PTP motion.	P=1000 A=200 S=300 ^
~	Execute CP motion with dynamic commands	~	This command executes CP motion.	P=10 ~ P=15 ~ P=20 ~
(bar)	Go Origin	(bar)  1  2	:Make the motor go origin 1: Make the motor go to position0 2: Sets the current position to 0	
]	Immediate Stop/Pause	]	Pauses the motor . To resume the program enter [bank#]. Pauses the motor and rests the program bank to its first command line.	
)	Motor Free	)	Turns the motor into a free state	
(	Enable Motor	(	Enables the motor in a free state.	



## Save and Inquiry Commands


Command	Function	Format	Description
+	Relative		Using the + directly after the P # changes the value indicated by P# command into a relative distance in a CW direction. To turn the motor in a CCW direction use a negative value for the speeds.
\$	Save	Write to EEPROM	




# **Appendix 4**

## Network Card Specifications


## Network Card




Master Motor




### Slave Motor



## Interface Card



### **Network Card + Interface Card(Master Set)**







## Appendix 5

### Custom Interface Cable

The Reliance Cool Muscle can be connected to a RS232 port on your controller or PC via the Y cable or the Master Motor set (Network Card + Interface card) that can be purchased from Reliance Precision Mechatronics LLP. PC RS-232 ports generate  $\pm 12V$  signals which are not directly compatible with the Reliance Cool Muscle serial input. You can also make your own cable to connect the Reliance Cool Muscle to a controller running TTL level signals as shown below.






## Appendix 6

to 1.  
**Index Signal**

Instead of an in-position signal you can have the Reliance Cool Muscle output index signals during origin search. Set K27 or K30 to 5 and K34 to 1.





## Appendix 7

### RS-485 Communications

In order to connect a Reliance Cool Muscle to a RS-485 serial connection, the motor's parameters need to be adjusted and a CM1DC1MBS Master Network Card needs to be connected as an interface to the motor. Please take care to set jumpers 1 and 2 on the Master Card's Serial Daughter Card to the appropriate settings. This can be found on page 16 of this user's manual.

The ID scheme with the RS-485 system is different from that of the RS-232 daisy chain network.

{ is used to preface the motors ID as follows:

{1 - {256 can be used as motor IDs.


{998 addressed all even number ID nodes.

{999 addressed all odd number ID nodes.


{1000 addresses all nodes

A RS-485 motor ID is stored in parameter K62. If K62=0, the motor works as if it is on an RS-232 connection. As RS-485 devices share the communications wires, automatic ID selection is not possible as it is with the daisy chain network. This requires the motor's ID to either be set prior to inclusion into the network or via the D command. The D command allows unaddressed motors to be addressed by using the motor's serial number as the identifying feature. Sending *Did*=serial# across the network will request the motor with the matching serial# to assign itself the *id*.

{0 is a software handshaking command that opens the RS-485 communications channel so that a motor can send data. When a motor sends data, the communications channel is automatically closed to other motors. This system prevents communications conflict over the shared wires.


**RS-485 Communications Example.****Possible Combined RS-485/RS-232 Network Layout**

The Reliance Cool Muscle networking scheme allows for both RS-485 devices and daisy chained devices. Each RS-485 device becomes a node with the RS-485 ID becoming a supernet address for the motors connected under it.





## RS-485 Wiring Schematic (PC to CM1DC1-MBS)





## Appendix 8

### Using the Analogue Inputs with a C-Type Motor

Starting with Firmware Version 1.12, it is possible to use the analogue inputs on the C-Type Reliance Cool Muscle to vary the motor's operation. All of the analog functions are tied to Input 4 on the motor. K39 is used to set Input 4's software low pass filter. Please refer to page 16 for wiring information. Input 4 can be accessed via the Network Card. Please refer to page 111 for this wiring information.

K64 is the parameter that is used to pick the function of the analogue input:


- K64=0: No analogue function
- K64=1: Input 4 varies the value of S0. Use K40 to set the speed range (+ and -).
- K64=2: Input 4 varies the value of P0. Use K41 to set the position range from 0 to 100xK41.
- K64=3: Input 4 varies the value of S13. Use K40 to set the speed range (+ and -).
- K64=4: Input 4 varies the value of P24. Use K41 to set the position range from 0 to 100xK41.
- K64=7: Input 4 varies all speeds by multiplying the target speed by a value. The multiplier's value's range is defined by K40. The range is from 0 to K41/100. K41's values can be between 0 and 4000.
- K64=8: Input 4 varies all positions by multiplying the target position by a value. The multiplier's value's range is defined by K41. The range is from 0 to K41/100. K41's values can be between  $\pm 32767$ .
- K64=9: Mimics the V-Type motor settings. When K38=0, Input 4 controls speed with K40 setting the speed range. When K38=1, Input 4 controls position with K41 setting the position range. Please refer to page 55 and 56 for a more detailed description.



# Appendix 9

## Using the H Infinity Auto Tuning Module (V2 Firmware)

The AutoTuning Hinif designing module within Cool Works Lite V4 is as follows:



### ***The Main Steps in Designing an H Infinity Controller***

*Input or estimate the load inertia.*

*Choose a suitable Response Rate ( $d_1$ ) and Robustness ( $d_2$ ).*

*Design controller by click "Design Gains" button.*

*Evaluate the design results through simulation*

*Send the design results to motor and activate step and frequency response tests.*


When you change  $d_1$  and  $d_2$ , the controller gains are recalculated automatically. The intermediate results are shown in the "Instruction Message and Results" window and graphic window.



There are three inertias that will be used in this document.  
“Load inertia for design” is the inertia value used during Hinif controller design.  
“Load inertia for simulation” is inertia value used when displaying a simulation with the designed Hinif controller.  
“Estimated inertia” is the inertia of your payload estimated by auto tuning module.

### **5.1 Design example of a 17L motor**

We will begin by designing a Hinif controller for a 17L motor.  
First, we need to estimate the payload attached to the motor.  
Click the “Determine Load Inertia” button, you will get the following window:



Using the default setting, click the “Start Auto Tuning” Button. The auto tuning module starts to work. The auto tuning process continues for 56 seconds as the motor oscillates in frequencies ranging from 1 to 100Hz. The final estimated inertia in this description is 110 gcm<sup>2</sup>. You can run the auto tuning routine several times. You should find that all the estimated inertia results are very close.

Remark: In this example, the payload for the motor is a coupling with an inertia is 9.0gcm<sup>2</sup>. The inertia of the position sensor is around 30gcm<sup>2</sup>. The standard inertia of the 17L rotor is 76gcm<sup>2</sup>. The total payload is 9+30+76=115gcm<sup>2</sup>.



Clicking the “Accept” button will set the load inertia in Hinf design to  $111 \cdot 76 = 34\text{gcm}^2$ .

Remark: You can choose different inertia for design. Usually, if you design a controller for heavier load inertias, it works fine if the real load inertia is smaller than that. For the 17L case, we can even set the load inertia for design to  $760\text{gcm}^2$  which is 10 times greater than that of the 17L rotor.

### ***Choose d1 and d2 for controller design***

We choose  $d_1=100$  &  $d_2=1.55$  by moving the sliders on the top right of the window. The resulting gains of the Hinf controller are as follows:

$$H_1 = 46$$

$$H_2 = -2427$$

$$H_3 = 3460$$


$$H_4 = 170$$

$$H_5 = 57$$

$$H_6 = 54$$

$$H_7 = 133$$

The  $H_0$  default is set to 100. The step response of the closed loop system is shown in the “step response” window. It says that the motor works fine.






### ***Simulation for a special load***

The simulation of the step response is done under the assumption that the real load is equal to the load used in control design. However, there are many cases in which the Hinf controller can tolerate inertia uncertainty. Moving the slider labeled "Load inertia for simulation" changes the simulation to show the step response for the designed controller using your chosen simulated inertia. We have set "Load inertia for simulation" to  $38\text{gcm}^2$ . The simulated step response is shown as the red trace.

### ***Test and verification - Test of step response***

To verify the design result, click the "Send to Motor" button. This sends the designed gains in the "Instruction Message and Results" window to motor. Choose the "Step Response" option in the right bottom corner and click "Start Experiment" button. This will force the motor to move a step with an altitude of 1000 pulse (50000pulse/rev). The result is as follows. Two step responses match very well. The red line is the simulated one and green one is the real response from motor.




The close trace of the green line, representing the actual move, shows our design is successful. Designing the Hinf controller is that simple!!!

### ***Test of frequency response.***

Choose the option "Frequency Response" in the right and bottom corner. To compare of the simulated frequency response to the treal one, we must calculate the frequency response one time. This can be done by choosing the "Complementary sensitivity




(T) in the combo box “Plot types” in the left bottom corner.  
Click on the “Start Experiment” Button. You get the frequency responses as follows.



They match well too.


### ***Test the real motion***

Going to chart window, you can do the following test by setting a motion of  $p=100000$ ,  $s=500$ ,  $a=100$ ,  $k37=3$ . This will rotate the motor 100 times. Execute the motion by sending ^.



## K Parameters

K #	Descriptions	Unit	Details	Unit	Details	K #	Descriptions	Unit	Details
K20	Baud Rate	K	0:384 1:96 2:192 3:76			K35	Analogue Output Function		0: Target position 1: Target position magnified by 8 2: Current Position 3: Current Position magnified by 8 4: Position Error 5: Position Error magnified by 8 6: Current Velocity/16 7: Current Velocity /2 8: q Real 9: tq8
K21	Full/Semi Closed	0.1°	0:full closed loop 1:36: Vector angle			K50	Manual bg travel distance	Pulses	Min:1 Max:100
K22	Time delay for Semi-dosed mode	msec	Min:10 Max:1000			K51	Creeping Speed	100pps	Min:1 Max:1000
K23	Motor Status Events		0: Poling Only 1:Running Status, Overflow, Over speed, Over Load/Current, IN POS, circle function and pushing torque 2: Input status 3: Output status 4: Status for Start, Stop, Enable, Disable, In/pause			K55	Inposition tolerance	Pulses	Min:1 Max:1000
K24	Timed Trigger Interval	Pulses	Min:10 Max:32767 (active when K34=7)			K56	Overflow Alarm Level	K pulses	Min:1 Max:32767
K25	Time delay for Slow Response Signal	0.1 sec	Min:1 Max:9 ie. K25=3133			K57	Overload Alarm Time Delay	nsec	Min:100 Max:10000
K26	Invert Input Signal	0:T/true 1:False ie. K26= 1101				K58	Software Limit( + )	100 pulses	Min:0 Max:32767
K27	Input function at target voltage level of Quick Response Signal		0:No Action 1:General Use 2:Origin Sensor 3:Manual Feed CCW 4:Manual Feed CW 5:Output Index signal instead of Inposition Signal 6:Execute Bank 1 ON START UP 7:Emergency Stop 8:Full Stop			K59	Software Limit( - )	100 pulses	Min:32767 Max:0
K28	Input function at the rising edge of Quick Response Signal		0:No Action 1:Alarm reset/Pause 2:Motor Free 3:Reset Counter 4:Execute Next Step 5:Execute Previous Step 6:Execute Bank 1 7:Go Origin 8:Manual bg CCW (Execute Bank 2 when K36=2) 9:Manual bg CCW (Execute Bank 3 when K36=2)			K60	Push Mode Current Level	%	Min:10 Max:80
K29	Input function at the falling edge of Quick Response Signal		Same Functions as K28 except 2:Enable Motor			K61	Push time	50msec	Min: 1 Max:30001
K30	Input function at target voltage level of Slow Response Signal		Same Functions as K27			K62	RS-485 Node ID		0: RS-232 mode 1~256: RS-485 ID -1~256: RS-485 Node ID , no auto report function
K31	Input function at the rising edge of Slow Response Signal		Same Functions as K28			K63	External Encoder Input		0:N one 1:Phase A only 2:Phase A and B
K32	Input function at the falling edge of Slow Response Signal		Same Functions as K28 except 2:Enable Motor			K64	Analog Input Function		0:N one, 1:50, 2:P0, 3:S13, 4: P24 5:S14, 6:P25, 7:Speed 0-Set speed, 8:Position Multiplier 9:Analog control only, K38
K33	Output Logic		0:Normally Open			K65	Slave Motor Baud Rate		0:384, 1:96, 2:192, 3:576, 4:768, 5:129, 6:173, 7:515 Set baud rate starting with the last motor on the network.
K34	Output Function		0:Command 1:Position 2:Alarm 3:CML O /F1 4:CML O /F2 5:Analog Output 6:Output on completion of Origin Search 7:Timed Trigger 8:Motor Free 9:Torque Limit reached - Push Mode Only			K66	Data Streaming		0: None. 1: Send back speed target 2: Send back real position 3: Send back real speed 4: Send back real current Iq 5: Position Real 6: Velocity Real 8:0: Torque data streaming (cNm)
						K67	Data Streaming Sample Timing	ns	0 - 30000
						K68	S Curve Function		0:S Curve with fixed timing 1:S Curve without timing
						K69	S Curve Gain		0 - 1024



# Reliance<sup>®</sup>

## Precision Mechatronics LLP

Precision Motion Control Components & Mechatronic Assemblies

Rowley Mills, Penistone Road, Lepton  
Huddersfield, HD8 0LE, England

Tel: +44 (0) 1484 601002

Fax: +44 (0) 1484 601061

[www.rpmechatronics.co.uk](http://www.rpmechatronics.co.uk)

e-mail: [sales@rpmechatronics.co.uk](mailto:sales@rpmechatronics.co.uk)