

## Using your pre-tensioning dispenser



Empty pre-tensioning dispenser



Compress the spring on the roll holder



Remove roll holder from main frame



Roll holder removed



Insert roll holder in to coreless roll



Push roll holder in to roll

## Using your pre-tensioning dispenser



Roll holder fully inserted in to roll



Ensure film come off the bottom of roll



Insert roll and holder back in to frame



Locate roll holder in to location point



Compress spring by pushing roll and holder



Insert opposite end of holder in to location point

# Using your pre-tensioning dispenser



Roll is loaded ready for threading



Threading path instruction shown on dispenser



Pull film from roll



Wrap around first roller



Thread under second roller



Film threaded and ready for use



Wrap goods with a fixed 50% pre-tension