



The “T” shaped item is the in-tank/in-line/compact filter.

The “boot shaped” item is the calmed inlet.

The 110mm o/d pipework is not supplied with the package, however this illustration is provided to assist with your on-site installation of the equipment.

The horizontal pipework should be installed with a slight gradient so that the rain water runs into the tank freely, and out of the overflow (when that level is reached), freely.

An installation tip is to fit the horizontal pipework all the way through the tank in a continuous piece upon initial installation. When the in-ground installation is complete and the pipework is firmly secured into place, then a section can be cut-out to accommodate the filter. Using 110mm slip couplers (as opposed to socket connectors with central registers) the filter can tightly and exactly replace the cut-out section of pipe, and the slip couplers can be moved back from along the pipe to affix the filter into the permanent position.

Finally the vertical 110mm pipework and the calmed inlet can be fitted onto the underside of the filter.

Tip: The filter needs to be reachable from cover level.

Tip: Position the filter to one side of the access opening, leaving enough room for the pump, etc to be removed for maintenance purposes as necessary.