

Packaging confidence through intelligent design.

Ripp 'n' Flow®

Ripp 'n' Take®

FLEXISTRONG® BLOCK BOTTOM DOLAV LINERS

FLEXISTRONG® BARRIER BAGS - COOKING BAGS - VACUUM BAGS

FLEXISTRONG® BLOCK BOTTOM SACKS

FLEXISTRONG® BLOCK BOTTOM LINERS

www.Flexipol.co.uk



aging confidence through intelligent design.



Ripp 'n' Flow®

This Flexipol[®]-patented easy open sack system was developed to provide a safe, hygienic solution for sensitive materials handling. Traditionally, all ingredients packed into either paper or polythene sacks have required a knife to open the top, prior to pouring the product into the mixer. Our customer's two main concerns were firstly, they had to use a knife and secondly, they had to slash the bag open which was producing foreign body contaminants such as paper, string and polythene, which would finish up in the product.

The Ripp 'n' Flow sack has been adopted by many ingredient manufacturers throughout Europe and the range of products being packed include; egg powder, breadcrumb, batter, spices, pasta, biscuit crumb, flavourings, dehydrated vegetables, whey and lactose powder and many other products.

How it works

The Ripp 'n' Flow[®] sack is an easy open sack solution which enables the end user to open the bag without the need for a knife.

Ripp 'n' Flow® offers the following benefits:

- Eliminates the need for knives to open bagged products
- No contamination from paper, string, crepe and plastic which occurs when using conventional paper and plastic sacks that can only be opened with a knife
- Block bottom feature is available which is designed to create a stand up pack for ease of filling, palletisation and reduced slippage

- Suitable for fully or semi-automatic filling lines
- Tamper evident design
- Available in a wide variety of sizes and thicknesses
- Can be printed in up to six colours















```
Certificate Number 43
BS OHSAS 18001
```

ber 4316 Certific 18001

Flexipol[®]



Flexipol Packaging Ltd. Bentwood Road, Carrs Industrial Estate, Haslingden Lancashire BB4 5HH

Tel: 01706-222792

Directions

At junction 18 on M62 Turn onto the M66 to head North to Bury Burnley and Blackburn.

Follow the M66 for 12 miles until it changes into the A56 (Duel Carriageway) at Edenfield and stay on the A56 for a further 2 Miles.

Keep in the left hand lane on the A56 and <u>bear-off keeping on the A56 to the left following Signs for</u> <u>Blackburn</u>. Do **NOT** go straight on to Rawtenstall on the A581.

Stay in the left hand lane on the A56 and immediately pass both the Haslingden turn off closely followed after $\frac{1}{4}$ mile by the junction to Blackburn and Grane (A6177).

400yds past the Grane turn off take the exit signposted to Carrs Industrial Estate.

Take the first road left and Flexipol are on your right hand side.