

www.grestec.co.uk

Bosco

porcelain stone



1.

2.

1. 200x905 11MM NAT		SIZE	THICKNESS	FINISHES
	1.	200x905	11MM	NAT

SKIRTING		
2.	100x603	



www.grestec.co.uk

Bosco

technical specification





Technical Characteristic		Standard	Average Values
	Water absorption	ISO 10545-3	Conforms
	Bending strength	ISO 10545-4	>45N/mm²
	Breaking strength	ISO 10545-4	Conforms
	Deep abrasion resistance	ISO 10545-6	Not applicable
† + +	Coefficient of linear thermal expansion	ISO 10545-8	a<7x10-6°C-1
Symula Symula	Resistance to thermal shock	ISO 10545-9	Resistant
	Frost resistance	ISO 10545-12	Resistant
	Resistance to chemical attack	ISO 10545-13	Resistant
	Stain resistance	ISO 10545-14	Resistant



www.grestec.co.uk

Bosco

maintenance





INITIAL WASHING

The initial washing is fundamental for good treatment results. The initial washing is aimed at removing any laying residues and building grime.

Product	Deterdek (1:5 diluted in water)	
Coverage	Deterdek (5 l per 100m²)	
Equipment	Single-disc professional polisher, liquid vacuum cleaner and cloth	
Procedure	 After the floor is swept and soaked with water, spread the diluted Deterdek onto the floor. Then scour with single-disc professional polisher. Vacuum the residue, rinse the floor well and then mop with a liquid vacuum cleaner or a cloth. 	

ROUTINE MAINTENANCE

The aim of the routine maintenance is to remove dirt and scuff marks. The routine maintenance must be carried out regularly.

Product	Filacleaner (Diluted in warm water)
Equipment	Cloth or mop
Procedure	 Dilute Filacleaner in warm water Wipe a cloth wet with the solution over the floor Rinse the floor in case of concentrated solutions of Filacleaner
	(For large areas the use of a cleaning machine is recommended)

SPECIAL MAINTENANCE

Special maintenance is carried out in case of very stubborn dirt, when the routine maintenance is not enough to restore the original look of the surface.

Product	Fila PS/87 (1:5 diluted in water)
Coverage	5 I per 100m2 (when diluted 1:5)
Equipment	Single-disc professional polisher
Procedure	 Dilute Fila PS/87 in 1:5 in water Apply to the floor previously soaked with water and leave for a few minutes Scrub with a single disc professional polisher Mop up residue with a liquid vacuum cleaner or cloth

