#### SUBSIDIARIES

#### BELGIUM BERNARD CONTROLS BENELUX BRUXELLES

info.benelux@bernardcontrols.com Tel +32 (0)2 343 41 22

CHINA **BERNARD CONTROLS CHINA** PEKID

bcc.info@bernardcontrols.com Tel +86 (0) 10 6789 2861

GERMAN **BERNARD CONTROLS DEUFRA** TROISDORF

bcd.mail@bernardcontrols.com Tel +49 22 41 98 340

ITALIA **BERNARD CONTROLS ITALIA** MILAN

info.it@bernardcontrols.com Tel +39 02 931 85 233

KOREA (REPUBLIC OF) BERNARD CONTROLS KOREA SEOUL

bck.info@bernardcontrols.com Tel +82 02-2270-3880

SINGAPORE BERNARD CONTROLS SINGAPORE SINGAPORE

bcsg.info@bernardcontrols.com Tel +65 65654227

SPAIN BERNARD CONTROLS SPAIN MADRID

info.spain@bernardcontrols.com Tel +34 91 30 41 139

UNITED STATES BERNARD CONTROLS Inc HOUSTON

bsales@bernardcontrols.com Tel +1 281 578 66 66

**OFFICES** BANGKOK BERDARD CONTROLS SOUTH-EAST ASIA

Tel +66 2 640 82 64

BERNARD CONTROLS

Tel +971 4 344 2010

BERNARD CONTROLS

youri.otradine@bernarda Tel +(7 499) 251 06 54

or +(7 916) 911 28 42

rates.net.ae

MIDDLE-EAST

bernact@e

MOSCOW

RUSSIA

ichounra

DUBAÏ

www.bernardcontrols.con nu@horoardcontrols 10 Back Office BERNARD CONTROLS

mail@bernardcontrols.com Tel +33 (0)1 34 07 71 00

AFRICA

Contact directly agents/distributors

Tel +420 548 213 233-5

AUSTRIA IPU ING PAUL UNGER WIED nardcontrols.com er@IPU.co.at Tel +43 1 602 41 49

DENMARK

ARMATEC A/S

COPENHAGUEN

jo@armatec.dk Tel + 45 46 96 00 00

CZECH REPUBLIC FLUIDTECHNIK BOHEMIA s.r.o. AGENTS AND DISTRIBUTORS BRNO brno@fluidbohemia.cz

Information on our network www.bernardcontrols.com

> 10 Back Office BERNARD CONTROLS Inc. bsales@bernardcontrols.com Tel +1 281 578 66 66

BRAZIL j**cn** Sao Paulo jcn@jcn.com.br Tel +55 11 39 02 26 00

- ASIA

Information on our network w. bernardcontrols.com

To contact our distributors Back Office BERNARD CONTROLS ASIA bcc.info@bernardcontrols.com Tel +86 10 6789 2861



FINLAND TALLBERG TECH OY AB ESP00 info@tallberg.fr Tel +358 0 207 420 740

GREECE PI&MS Entreprises Ltd ATHENS Tel +30 210 608 61 52

HUNGARY APAGYI TRADEIMPEX KFT BUDAPEST bela.apagyi@mail.tvnet.hu Tel +36 1 223 1958

MOROCCO **AOUATEL** sor CASABLANCA aquatel@wanadoo.net.ma Tel +212 22 66 55 71

POLAND ARNAP BIELSKO-BALA Sales@arnap.pl Tel +48 33 81 84004

BERNARD

CONTROLS

ALLSCHWIL info@matokem.aa Tel +41 61 483 15 40 TURKEY

OTKONSAS ISTADBUI sales@otkonsas.com Tel +90 216 326 39 39

> UNITED KINGDOM ZOEDALE PIC BEDFORD enquiries@zoedale.co.uk Tel +44 12 34 83 28 28

POLAND

Marco Varsovie

BERTSHAM

matzanke@pol.pl Tel +48 22 864 55 43

aqr@wol.co.za Tel +27 11 432 58 31

SWITZERLAND

MATOKEM AG

SOUTH AFRICA A-Q-RATE AUTOMATION CC

**Exhaustive list of agents** and distributors on www.bernardcontrols.com

A121/03 All data ir

Reliability, Security, User Friendly.



BERNARD CONTROLS SA 4 rue d'Arsonval - B.P. 70091 95505 Gonesse CEDEX France Tel.: +33 (0)1 34 07 71 00 Fax: +33 (0)1 34 07 71 01 mail@bernardcontrols.com www.bernardcontrols.com







### **EXPLOSION PROOF INTELLI+® ACTUATORS** SQX & STX RANGES



# PREMIUM Reliability Security User Friendly

BERNARD C The BC Prer innovative a and operatio Decades of as nuclear a and our com Moreover, B extremely la

tuitive cont

| t in experience    | > | 4  | User friendly & int |
|--------------------|---|----|---------------------|
| e overview         | > | 6  | Versatile enclosur  |
| ble technology     | > | 8  | Easy maintenance    |
| rity at all levels | > | 10 | Hardwired contro    |

BERNARD CONTROLS introduces the BC Premium label. The BC Premium label is the guarantee of high performance, reliable and innovative actuator solutions designed to sustain severe environmental and operational conditions.

Decades of return of experience from very demanding applications such as nuclear qualified valves actuation have shaped our technical orientations and our commitment to quality and safety.

Moreover, BC Premium labelled products offer user-friendliness and extremely low level of maintenance requirements.

| trols | > | 14 | INTELLI+ Layout        | > | 21 |
|-------|---|----|------------------------|---|----|
|       | > | 16 | Fieldbus communication | > | 22 |
|       | > | 18 | Dimensions & Technical |   |    |
|       | > | 20 | Specifications         | > | 24 |
|       |   |    |                        |   |    |



# invest in **experience**

**Power Generation** 



Water

#### BERNARD CONTROLS RELIES ON 75 YEARS OF CONTINUOUS EXPERIENCE AND KNOW-HOW TO OFFER TOTAL & DURABLE SOLUTIONS FOR INDUSTRIAL VALVES' AUTOMATION

#### 

Expertise is our business specialty. Our credo follows from the technical requirements of our products' fields of application. Our products are qualified and approved by the largest prime contractors and industrial players in France and abroad. By improving our competencies and the efficiency of our processes, we enhance the quality of our products and services.

Commissioning electric actuators requires specific expertise and care. This is specially true when the motorised valve is controlled by a complex system such as a fieldbus. That is the reason why our specialists are available to provide the adequate support to our customers for:

- adaptation on the valve
- installationset-up
- start-up

The nuclear market has shaped our expertise, our commitment to quality and to the control of your processes. By fulfilling these requirements, we undertake to make no compromise on security.

Everyday, our technicians are available to quickly go on site for:

- periodic actuator functional check-up
- preventative maintenance operations
- diagnosis and repair

#### Controls and Confidence Confidence Confidence Confidence Confidence Confidence Confidence Confidence Confidence

BERNARD CONTROLS is an international industrial technological company acknowledged for its know-how and expertise in the most demanding markets. The control of processes is our business and the cornerstone of your confidence. Regular training sessions are organised for our customers and our distribution network. These sessions are held either in France, at our local service centre or at customer site. Actuator technology, setting, operating and maintenance are among the most popular topics covered.



Industries, HVAC & Marine



Oil & Gas

#### 

# Range overview

#### > Multiturn actuators

STX Range description

- Available torque range from 60 to 25 000 Nm
- Ex d/NEMA 7 explosion proof enclosure
- ATEX, IEC Ex , CSA/FM, CEPEL, GOST-EX Certified
- IP68 (10m / 96h) as standard
- Available for ON/OFF and Modulating Class III applications
- INTELLI+ controls as standard
- Electromechanical versions (switches) on request (refer to specific datasheet)



**BERNARD CONTROLS multiturn STX actuator** 



BERNARD CONTROLS STX actuator on a bevel gearbox

#### >Quarter-turn actuators

SQX Range description

- Available torque range from 200 to 500 000 Nm
- EXd/NEMA 7 explosion proof enclosure
- ATEX, IEC Ex , CSA/FM, CEPEL, GOST-EX Certified
- IP68 (10m / 96h) as standard
- Available for ON/OFF and Class III applications
- INTELLI+ controls as standard
- Electromechanical versions (swithes) on request (refer to specific datasheet)



BERNARD CONTROLS quarter-turn SQX actuator

#### > Other Explosion proof solutions



 Quarter-turn failsafe
 Failsafe with reliable springreturn technology
 Fast and shock-free valve travel

- during emergency operation
- Maintenance-free
- > EEx d/NEMA 7 explosion proof
- enclosure IP67 as standard



- EEx ed quarter-turn actuators
- > Available torque range from 60 to 800 Nm
- > EEx ed explosion proof enclosure
- > IP67 as standard
- > Available only in electromechani-
- cal version (switches)
- > Compact and robust





BERNARD CONTROLS STX actuator on a worm gearbox

#### • Intensive Modulating Class II

- > 100 % duty service
- Change of position every 2 to 3 seconds
- Quarter-turn, linear, multiturn and lever movements



7

# **Reliable technology** Heavy duty design

BERNARD CONTROLS actuators offer a robust and reliable design based on more than 75 years of experience in demanding markets.

#### >Trouble-free operation

- Gearing is self-locking at all speeds.
- Continuous gear drive between motor and valve.
- Main mechanical parts unaffected by vibration.
- No preventative maintenance required. Gearing is lubricated for lifetime.
- High efficiency gearing reduce wear.

#### > Power to spare

Asynchronous motors used for Explosion proof series has the highest possible ratio between starting torque and nominal torque. With this hypothesis of design, actuators can operate in any difficult case and can also support repetitive starts.

- Asynchronous motor with high starting torque.
- Excellent starting torque / nominal torque ratio.
- On/Off operation: 30% motor duty rating. Up to 360 starts per hour at peak of operation.
- Modulating Class III: 50% motor duty rating. Up to 1 200 starts per hour at peak of operation.
- Easy to remove motors with sealed ball bearings fitted at front and rear.



#### Accurate information

Thanks to ABSOLUTE SENSORS, which constantly measure the position & torque of your valve, INTELLI+ get precise and reliable information.

• Proven measurement principles

- > Torque is measured by a dynamometric balance (calibrated springs) offering a high level of precision, an excellent repeatability as well as a very low long-term drift. The short response time of the system allows an early detection of the valve seat reach thus reducing the over-torque applied to the valve.
- > The position sensor is mechanically linked to the main gear and delivers a proportional signal with no risk of loss of position with time.
- Actual valve information
- > Both position and torque are measured as close as possible of the output of the actuator (see picture below). This means that what is measured is really representative of the actual valve torque and position.
- > The valve position/torque curve is available at any time directly on the INTELLI+ graphical display (see page 18)
- Absolute sensors
- > Thanks to absolute sensors, the position and torque information are not lost even after a loss of power supply. In fact, as soon as the power comes back, the INTELLI+ electronics has just to read the value given by the sensors and update the feedback signals to the control room. Therefore, this system does not require any battery back-up.



BERNARD CONTROLS' position & torque absolute sensors are mechanically linked to the output shaft





# Security at all levels Non intrusive settings

Thanks to INTELLI+, commissioning is simplified and can be performed in a nonintrusive way. Upon user's request the actuator parameters can be preset at the factory. In this case, start-up simply consists in setting the actuator on the valve.

#### > Manual or automatic setting

During the actuator on valve setting procedure, the user is guided step by step by INTELLI+:

- > Choice of closing (on torque or on position),
- > Choice of direction to close,
- > Drive the actuator to the closed and the open position and validate the position
- > The setting can be done automatically or manually by choosing the closed or open positions.

For certain valves, as an example gate valves equipped with back seat, INTELLI+ can automatically perform this setting: the actuator detects the extreme positions (using the torque limiter), tests the inertia in order to optimize this setting.

#### > Infrared communication

- INTELLIPOCKET is a real industrial pocket PC which eases the engineer's job on site both for setting up and throughout product lifetime. Exists in Explosion proof version. INTELLI+ offers the possibility to communicate with a standard laptop through an infra-red link with INTEL-LIKIT or INTELLIPOCKET.
- INTELLIKIT is a communication kit necessary to communicate with INTELLI+, made of the INTELLI-



SOFT communication software developed by BERNARD CONTROLS and an infrared transmitter receiver connected to USB. All functions (use, settings/ configuration, status, etc...) are available through the computer.

#### Bluetooth communication (option)

As an alternative, Bernard Controls proposes the Bluetooth technology which uses radio signals to communicate between the PC with INTELLISOFT and the Intelli+ controls.

- Accessibility: the user does not need to position himself in front of the actuator and can move its computer without loss of communication.
- Simplicity and security: the PC/PDA automatically detects all devices located at a maximum distance of 10m. Each actuator holds a unique identifier and the connection can be protected with a password.

#### Actuator & valve protection

#### > Phase monitoring

INTELLI+ includes an automatic phase correction device. In case of 3 phase power supply, whatever the power connection, the actuator always rotates in the correct direction. If one of the phases is not present, the actuator stops automatically and the fault relay drops.

#### Protection of change in direction

An automatic delay protects the actuator and valve from all rapid rotational direction changes while limiting the effects of the mechanical pieces in inertia.

#### Signalling continuity (option)

The actuator is totally autonomous and does not require a battery to operate. However, a signalling battery back-up optional board can be added for signalling purpose only. This battery is activated in case of loss of power supply and allows:

- to use the INTELLI+ displau.
- > to update remote signalling (valve position, alarms, ...)
- > to refresh fieldbus information

Low battery condition is automatically detected by the INTELLI+ and a warning message is sent. A low battery condition does not have any consequence on actuator operation.

Note: a 24VDC external power supply input is always present on the INTELLI+ board to achieve the same functionality and more. In case of hardwired control, 24VDC voltage can be supply trough the same multiwire cable as input/output signals.

#### > Fire protection (option)

Fire could be a major cause of damage in Oil & Gas installation. For this reason, BERNARD CONTROLS can propose on option for Explosion proof actuators, two efficient systems: a fire jacket or an intumescent coating. These two systems allow the actuator to continue operating for 30 minutes in fire temperature over 1000°C.

#### > Motor thermal protection

To prevent motor overheating, a thermal cutoff is embedded in the motor winding (in the case of a low maximum admissible surface temperature (ATEX T6 i.e), a surface thermal cutoff is added into the motor.

#### > SIL 2 (option)

Safety Integrity Level (SIL) option is guaranteeing a very high level of confidence with diagnostic capabilities on the valve position measurement and ESD command chains. Through its innovative Intelli+ interface and according to IEC61508 & 61511 standards, Bernard Controls is the first to propose a SIL2 function guaranteeing also the valve position monitoring.





Thanks to BERNARD CONTROLS actuators' smart functions, the user maximizes site protection.

#### > Partial stroking

Partial stroking is a key specification of BERNARD CONTROLS actuators which enables to check the availability of the connected MOVs.

This test consists in the execution of a very short return travel.

Starting position as well as partial stroke amplitude are programmable.

This command can be either hardwired or sent by fieldbus. A warning is generated in event of problems occuring during this test.

#### > Fieldbus lightning protection > Emergency shutdown (ESD)

In case of lightning stroke on the fieldbus line, overvoltage spreads along the line. If your actuators are not protected, some of the electronic components may breakdown and have to be replaced. The lightning protection included in our explosion proof actuators acts as a shield and discharges overvoltage. Voltage goes back to standard level and the automation of your valves can resume.

#### > Fault monitoring relay

One changeover (SPDT) relay indicates that the actuator is unavailable. This fault monitoring relay reports 5 types of defaults as a standard. Additional defaults to be reported can be easily added by the user (see Configuration on page 34). The monitoring relay is always energized and drops out only in event of a fault.

#### > Protection by password

A password can be entered to protect access to parameters modification and actuator on valve setting.

#### > Alarms indication

INTELLI+ continuously monitors the actuator performances. Up to 17 different types of faults and alarms can be reported (refer to Configuration on page 34 for a complete list of alarms).

An exclamation mark in a triangle on the local display indicates an alarm.

The actuator can still operate normally in case of an alarm, for example there is an alarm after 'Too many starts'. The alarm will automatically reset when the fault no longer exists.

ESD (Emergency Shut Down) is a remote emergency control signal with priority over all other commands. Depending upon the valve operation, ESD can be configured as an Open, Close or Stop command. To increase the availability of the actuator in extreme conditions, ESD can be set to ignore a torque overload condition.

#### Timer

This function enables an increase in the operating time of the actuator, i.e. to avoid water-hammer effect in a pipe.

Travel time can be programmed independently in both opening and closing directions.

It is also possible to apply the timer function to a limited section of the stroke.



# User friendly & intuitive controls



#### >Graphical display

- Menu guided settings using clear messages. Language can be freely selected among: Chinese, English, French,
- German, Italian, Portuguese, Russian and Spanish • The LCD display gives a clear status of the actuator
- and of the control system:
  - > Position in percentage (for example 5% Open) When the valve is fully closed, "closed" is displayed When the valve is fully open, "open" is displayed
  - > Actual torque expressed as % of actuator maximum torque
  - > Alarm/fault flag

#### > Main display indications

| 5% Open<br>Torque 20% | Valve position in % of opening valve torque can also be displayed in % of actuator maximum torque.   |
|-----------------------|--|
| Ĩ                     | Local controls inhibited by the remote controller.   |
| ESD                   | Emergency shutdown signal received.  |
| r                     | Infrared link is detected.   |
| *                     | Bluetooth link is detected.  |
| ٨                     | This icon is displayed in case of alarm.   |
| 0% <u>\</u>           | When a positioner is built-in, the set point value is displayed in percentage. This indication is blinking in case of loss of control signal.  |
| вus                   | This icon indicates that the fieldbus board is installed. The square displays the status of the communication: no communication, communication in progress or faulty module.   |
| 1[]2[]                | In case of redundant fieldbus interface, two squares are displayed. The squares display the status of each communication line: no communication, a channel is acting as primary or backup, communication in progress or a faulty module. |



#### Autonomous

- INTELLI+ user interface is intuitive.
- INTELLI+ operation does not rely on a battery.
- No tool is needed to have access to the menu in any case.

#### Local signalling

- 2 LEDs (red/green) indicate the position (close/open) at ends of travel, and direction of running (blinking).
- Red and green LED can be freely assigned to open or closed positions.

#### Local commands

- The red selector enables the operator to choose remote control, local control function and stop during position (padlock not supplied).
- The blue selector allows local operation of the actuator in either direction: OPEN or CLOSE.
- Local commands can be inhibited remotely.
- the display.. Password can be entered to protect access.

#### >User friendly menu



Selector to validate the choice (ok)



LANGUAGE: to change the language of the display (8 languages available)

CHECK: to read all the actuator parameters and configuration (activity, alarms, commands, torque, data sheet, position, positioner, signalling, timer, fieldbus)

SET UP: to set up the actuator on the valve (closing mode, close direction, position setting)

CHANGE: to modify the actuator configuration (activity, commands, torque, data sheet, position, positioner, signalling, timer, fieldbus)

EXIT SETUP: to exit the actuator setup

operation. It can also inhibit all use of the actuator (OFF position). This selector switch can be locked in each

• If necessary, operating parameters can be modified with the local control buttons by following information on



Selector to navigate up and down into the menu

# Versatile enclosure

#### > Separated box

The separated control box configuration can be specially useful when the actuator has to be mounted:

- in a difficult access (manhole, in a high position,...)
- > on a highly vibrating device

 in an excessively high or low temperature area
 The maximum distance between control and actuator is 50 meters.




#### > Double-sealing protector

Two barriers fitted with O-rings insure an optimum protection against water ingress into the electronic compartment.

This protection remains effective even if the cover has not been closed properly or if the cable glands have not been tightened.

Protection is also ensured for the local control selectors thanks to internal reed switches which prevent moisture ingress.



Double-sealing principle





Explosion proof INTELLI+ actuators

# **Easy maintenance**

#### **Diagnostic & preventative maintenance**

Thanks to its absolute sensors and its microprocessor technology, INTELLI+ continuously monitors its components as well as the actuator status and measures some important valve parameters. INTELLI+ provides users with a great deal of information to help with system diagnostic and aid in scheduling their valves preventative maintenance. INTELLI+ helps maximise process availability by reducing maintenance downtime.

#### > Actuator activity

Parameters are available on the display through the menu to check the activity of the actuator:

- > Number of starts: total starts since the actuator manufacturing.
- > A partial counter can be selected.
- > Running time: total running time since the actuator manufacturing.
- > A partial counter can be selected.
- > Starts last 12h: number of starts in the last 12 hours (to check the modulating activity i.e.).
- > Handwheel action: indicates if the handwheel was operated by manual operation since the last electrical command.

#### Data sheet memorised

INTELLI+ stores in its memory the data sheet of the actuator: customer tag number, BERNARD CONTROLS serial number, duty rating, classification level, manufacturing date, etc.

#### Self-monitoring functions


INTELLI+ checks the operation of its components, particularly torque sensor, position sensor, microprocessor and EEPROM memory.

INTELLI+ constantly monitors its performance in order to detect any problem of over-travel, jammed motor, rotation direction, lost phase, motor thermal overload and many others.

Refer to Configuration page 34 for the complete list of alarms.

#### >Valve torque curve

INTELLI+ memorizes the valve torque data during its last opening and closing operation. This information can be recalled on the



actuator display. The curve displays the position from 0 to 100% and the torque from 0 to 100%. The data can be uploaded in the computer with INTELLIKIT on the INTELLIPOC-KET or by fieldbus (optional) in order to be displayed with the INTELLISOFT software as a curve (torque vs. position) or data in a spreadsheet.

#### Easy site management

#### Declutch-free handwheel

- Patented manual override system.
- Differential geardrive allows the handwheel to be operated without releasing a clutch beforehand.
- The handwheel can therefore be operated under all conditions, even when a high torque is applied to the valve (i.e wedge gate valve closed tight).
- Electric command has priority over manual override.

#### > Detachable thrust unit

For rising stem valves applications, the STX actuators thrust unit is detachable. In fact, the A form is bolted on both actuator and valve flanges. This offers a lot of flexibility and safety at the installation phase as well as for maintenance operations. For example, if the actuator has to be dismounted from the valve, the thrust unit can be left in place. This enables to lift up the heavy actuators without "unscrewing" them and also keeps the valve stem in position.

#### > Bus continuity

Fieldbus is advantageous because it allows getting more information while reducing the overall wiring on site. However, when you break up the continuity of the line, for instance because of one actuator being retrieved from the field for maintenance, your whole installation is affected since the signal cannot circulate anymore.

BERNARD CONTROLS actuators can host a special Profibus connection board<sup>1</sup>, located in the cover of the wiring compartment. This cover can simply be removed from the actuator and closed tight by a special type plate. The resulting so-called "BU" type box ensures continuity of signal throughout the line even when the actuator is removed from the field. Maintenance is then facilitated since you can disconnect an actuator for repair or replacement, while maintaining signal transmission. The "BU" box is explosion proof.

1 - Standard on Explosionproof actuators on option for Waterproof actuators







# Hardwired control

#### >Wire by wire command

Remote control can be achieved using a 10 to 250 V external voltage supply or by dry contacts which use the actuators internal 24 VDC voltage supply. This control can be configured as a pulse or self-holding remote command. Inputs on the board are completely isolated by opto-isolators. It is also possible to control the actuator with a unique external contact, using one of the two functions «Priority to open» or «Priority to close».

#### > Remote indications

Remote indication is done through 4 relays, with the possibility of 23 available information.

Voltage free relays maintain their positions without battery backup. Normally open or normally closed contact can be chosen. An optional board with 3 single option relays allows reporting of 3 additional indications.

#### > Position & torque transmitter


INTELLI+ can be equipped with an analogue position & torque feedback board. This module delivers a 0 / 4-20mA signal proportional to the percentage of the valve opening. A voltage signal (i.e. 0-10V) can also be obtained by connecting an external resistance. The board can be either supplied by an external (12 to 32 VDC) source of power or internally, by the INTELLI+ electronics. This module also delivers a 4-20mA signal propotional to the real torque of the valve.

#### Positioner

A positioner board can be installed into the INTELLI+ to allow the operator to drive the valve to intermediate positions (Class III modulating). The positioner module has been designed to work with either current (i.e. 4-20mA) or voltage (i.e. 0-10V) analogue signals:

- > One input signal: the set-point
- > One output signal: the actual valve position feedback

The input and output signals are fully isolated from each other. The setting procedure is fully automatic and is performed in a non-intrusive way. The dead band can be adjusted by the user.





Explosion proof INTELLI+ actuators

# Fieldbus communication

The fieldbus, present on a large number of installations, is used more and more to communicate information and commands with multiple actuators and devices wired in series on a single pair of wires. Thus, the number of information available from each actuator can be multiplied while reducing the overall cost of wiring on the site.

POINT-TO-POINT CONNECTION

EACH ACTUATOR HAS TO BE CONNECTED TO THE CONTROL CABINET

Valve 1

Valve 2

Valve 3

MANY UNITS CONNECTED ON A SINGLE PAIR OF WIRES; ALL COMMANDS AND SIGNALS CAN BE TRANSMITTED BY THE BUS

Valve 2

MULTIDROP CONNECTION

BERNARD CONTROLS actuators can be connected to most of the standard fieldbuses available on the market:

- PROFIBUS DP,
- FOUNDATION FIELDBUS,
- MODBUS RTU,
- Other fieldbus on demand.

For more security, redundant fieldbus ensures continuous operation, even in case of a bus line disruption. Indeed, all elements of the bus line (bus controller, lines, actuators interfaces) are doubled.

#### Open versus Proprietary systems :

Two physical concepts of fieldbus are available from various providers.

#### • The «Proprietary» so-called system:

This is a technology designed by a device manufacturer for his own needs. A «Proprietary» system always includes the actuators with the specific bus interface, but also the bus controller located at the line head-end. Only the products proposed by the bus controller manufacturer can be installed on the bus.

#### • «Open» systems:

One using standard international fieldbuses so various manufacturers can supply compatible controllers and interfaces. This type of technology is proven, reliable and offers fast response time

BERNARD CONTROLS chooses the «open» system for all its fieldbus solutions.

#### > BERNARD CONTROLS Master Station






122






- Based on robust PLC technology and open fieldbus protocol
- Up to 120 actuators and 10km distance
- Fast response time. Standard scan time 1 to 3 s whatever the distance and number of actuators connected
- 1 to 3 lines starts
- Simple or redundant configurations
- Overall start up time reduced to the minimum

# **STX Performance data** Multiturn explosion proof actuators




# **STX Dimensions**




|        |        | Ster             | m diameter (r     | nm)     |         |     | a3<br>(A-B1 form) | a3<br>(B3 form) | Weight |
|--------|--------|------------------|-------------------|---------|---------|-----|-------------------|-----------------|--------|
|        | Flange | Type A<br>(max.) | Type B1<br>(max.) | Type B3 | a1 max. | ٥2  |                   |                 | (kg)   |
| STX6*  | F10    | 30               | 42                | 20      | 569     | 540 | 431               | 373             | 41     |
| STX10  | F10    | 38               | 42                | 20      | 603     | 540 | 386               | 328             | 48     |
| STX20  | F10    | 38               | 42                | 20      | 613     | 540 | 386               | 328             | 49     |
| 51720  | F14    | 38               | 60                | NA      | 613     | 540 | 405               | NA              | 50     |
| STX40  | F14    | 48               | 60                | 30      | 726     | 621 | 438               | 361             | 80     |
| STX60  | F16    | 60,5             | 80                | 40      | 808     | 668 | 505               | 405             | 100    |
| STX100 | F16    | 60,5             | 80                | 40      | 711     | 668 | 505               | 405             | 102    |
| 51×100 | F25    | 60,5             | 100               | NA      | 711     | 668 | 535               | NA              | 105    |
| STX140 | F25    | 70               | 100               | 50      | 829     | 698 | 559               | 429             | 137    |
| STX175 | F25    | 85               | 100               | 50      | 1056    | 797 | 661               | 523             | 295    |
| STX220 | F30    | 90               | 120               | 60      | 1056    | 797 | 661               | 523             | 316    |


\* Stem lift limited to 130 mm. Please refer to detailed drawing for more details.





#### Multiturn explosion proof actuators







25 / / / /



# **STX Dimensions** Multiturn explosion proof actuators





|               |        | Stem diameter (mm) |                   | al may                   |      |      | Approx.        |
|---------------|--------|--------------------|-------------------|--------------------------|------|------|----------------|
|               | Flange | Type A<br>(max.)   | Type B1<br>(max.) | a1 max.<br>(H if higher) | ۵2   | ۵3   | Weight<br>(kg) |
| STX40+AxM24   | F16    | 70                 | 85                | 726                      | 621  | 705  | 97             |
| STX60+AxM33   | F25    | 85                 | 118               | 808                      | 668  | 853  | 142            |
| STX100+AxM43  | F30    | 102                | 132               | 808                      | 668  | 891  | 162            |
| STX140+AxM70  | F35    | 115                | 145               | 698                      | 829  | 917  | 250            |
| STX175+AxM70  | F35    | 115                | 145               | 1000                     | 1220 | 1013 | 420            |
| STX175+AxM90  | F35    | 122                | 190               | 1000                     | 1220 | 1104 | 455            |
| STX220+AxM90  | F35    | 122                | 190               | 1000                     | 1220 | 1104 | 476            |
| STX220+AxM111 | F40    | 140                | 210               | 1000                     | 1220 | 1180 | 626            |

## Mounting flange Specifications

Type A STEM NUT

Type B1 Large dia.





Thrust accepted

Thrust not accepted





#### > ISO 5210 requirements

| Flange | Max torque | Max. acceptable thrust<br>(Type A) | Mounting bolts     |
|--------|------------|------------------------------------|--------------------|
| F10    | 100 N.m    | 40 000 N                           | 4 x M10 / d=102 mm |
| F14    | 400 N.m    | 100 000 N                          | 4 x M16 / d=140 mm |
| F16    | 700 N.m    | 150 000 N                          | 4 x M20 / d=165 mm |
| F25    | 1200 N.m   | 200 000 N                          | 8 x M16 / d=254 mm |
| F30    | 2500 N.m   | 325 000 N                          | 8 x M20 / d=298 mm |







Type B3 SMALL DIA.



Thrust not accepted

Type C CLAW COUPLING



Thrust not accepted











# SQX Performance data

#### Quarter-turn explosion proof actuators

# **SQX** Dimensions






|        |         | Stem si        | ze (mm)          |         |     |     |                |
|--------|---------|----------------|------------------|---------|-----|-----|----------------|
|        | Flange  | Bore<br>(max.) | Square<br>(max.) | a1 max. | ۵2  | ۵3  | Weight<br>(kg) |
| SQX 18 | F07/F10 | 32             | 32               | 568     | 466 | 409 | 33             |
| SQX 25 | F07/F10 | 32             | 32               | 616     | 466 | 409 | 35             |
| SQX 50 | F07/F10 | 32             | 32               | 617     | 466 | 409 | 36             |
| SQX 80 | F12     | 36             | 40               | 617     | 466 | 440 | 41             |

\* Many other possibilities up to 610.000 Nm. For more details, please contact us



#### Quarter-turn explosion proof actuators




29////


Explosion proof INTELLI+ actuators



# **SQX** Dimensions

#### Quarter-turn explosion proof actuators





|                    |             | Stem si        | ze (mm)          |         |     |      | Approx.        |
|--------------------|-------------|----------------|------------------|---------|-----|------|----------------|
|                    | Flange      | Bore<br>(max.) | Square<br>(max.) | a1 max. | ۵2  | ۵3   | Weight<br>(kg) |
| STX6+RS108         | F10/F12/F14 | 60             | 40               | 569     | 466 | 612  | 57             |
| STX6+RS258         | F14/F16     | 80             | 55               | 569     | 466 | 755  | 77             |
| STX6G+RS438        | F16         | 80             | 55               | 569     | 466 | 701  | 77             |
| STX6+RS1008G       | F25         | 100            | 70               | 569     | 466 | 829  | 105            |
| STX20+SBWG05/1SDM  | F25/F30     | 115            | /                | 666     | 540 | 845  | 160            |
| STX20+SBWG55/1SDM  | F25/F30     | 125            | /                | 613     | 540 | 890  | 183            |
| STX40+ SBWG06/1SBM | F30/F35     | 140            | /                |         |     |      |                |
| STX40+SBWG07/1SBM  | (F35) F40   | 180            | /                | 868     | 621 | 1165 | 372            |
| STX40+SBWG75/1SBM  | (F40) F48   | 210            | /                | 958     | 621 | 1332 | 489            |
| STX60+SBWG08/1SBM  | (F40) F48   | 225            | /                | 908     | 666 | 1367 | 648            |

\* Many other possibilities up to 610.000 Nm. For more details, please contact us

# **Explosion proof actuators**

#### **Technical Specifications**

|                           |                                     | •   |
|---------------------------|-------------------------------------|---|
| GENERAL<br>SPECIFICATIONS | Torque range                        | Multiturn<br>• direct mount : 60 to 2200 N.(<br>• with gearbox : up to 20,000 l<br>Quarter-turn<br>• direct mount : 200 to 800 N.(<br>• with gearbox : up to 500,000        |
| S                         | Type of service                     | ON/OFF - Modulating Class III. Class  |
|                           | Casing                              | Cast aluminium.<br>Ductile cast iron for models STX175  |
|                           | Ingress Protection                  | IP68 10m / 96h & NEMA 6 (C.S.A C  |
|                           | Controls location                   | As standard, the INTELLI+ controls of<br>On option, the INTELLI+ can be mou<br>(maximum distance between actuat   |
| CTION                     | Explosion proof ATEX                | ATEX Directive 94/9/EC - CENELEC<br>As standard: Ex d II B T4 (option T5<br>On request: Ex d II C T4 (option T5   |
| - PROTE                   | Explosion proof C.S.A.<br>C and US  | NEMA 7 - NEMA 9 certified<br>C22-2, FM3600, FM3611 and FM36<br>Class I Group C, D div 1&2 (option G   |
| ENCLOSURE - PROTECTION    | Explosion proof IEC Ex              | IEC Ex - standard IEC 60079-0, IEC<br>As standard: Ex d II B T4 (option T5<br>On request: Ex d II C T4 (option T5   |
| EUG                       | Ambiant temperature operating range | • IIB standard: -20 +70°C<br>• IIB low temperature option: -50<br>• IIC option: -20 +60°C   |
|                           | External corrosion<br>protection    | Standard paint system: Zinc rich prin<br>Optional special anti-corrosion prote<br>All cover fasteners captive and stair   |
|                           | Double sealing<br>Protection        | The control section of the actuator<br>components<br>Terminal compartment < 2 litres, no  |
| DTOR                      | Motor technology                    | TENV type Totally Enclosed Non Ve<br>Class F insulation class<br>Integral thermal overload protection<br>Easy to remove with sealed ball bea                                |
| M                         | Motor duty rating                   | S4 motor service (intermittent servi<br>• S4 - 30% for ON/OFF operati<br>• S4 - 50% for Modulating class  |
|                           | Gearing                             | Self-locking at all speeds  |
| MECHANICAL SPECIFICATIONS | Manual override                     | Handwheel which does not rotate of<br>• Automatic switch between manuce<br>• Manual control gear ratios: STX6 1<br>STX175/STX220 1:31<br>• Maximum rim force to apply confo |
| CAL SPEC                  | Output flange                       | <ul> <li>Multiturn actuators flanges comply</li> <li>Quarter-turn actuators flanges con<br/>Flanges for valve special top works</li> </ul>                                  |
| HADIC                     | Output drive                        | Removable sockets on SQX and STX<br>Direct machining in the output quad   |
| MEC                       | Vibration<br>Resistance             | lg (9.8 m/s²) at 10-500 Hz<br>(Contact our marketing dept. for hig  |
|                           | Lubrication                         | Actuators are lubricated for product  |



) N.m

m )0 N.m

s II: refer to specific documentation

75 / STX220

and US certified)

are integral to the actuator ounted in a separated box ator and controls = 50m)

E EN 60079-0, EN60079-1, EN61241-0, EN61241-1 standards 5 or T6) and Ex t DA21 IP68 T=135°C (option T=100°C, T=85°C) or T6)

615 standards Group B)- Class II Group E, F, G div 1&2

C60079-1, IEC61241-0, IEC61241-1 standards 5 or T6) and Ex t DA21 IP68 T=135°C (option T=100°C, T=85°C) 5 or T6)

.+70°C

rimer, epoxy undercoat and RAL5002 blue protection polyurethane top coat tection for marine, aggressive or abrasive atmospheres inless

is totally isolated from the terminal compartment to protect electronic

o source of ignition

/entilated, squirrel cage motors (VAC)

earings fitted at front and rear

vice on start-up) to IEC 34-1 tion - up to 360 starts per hour iss III - up to 1,200 starts per hour

during motor operation. al and electrical operation without clutch release lever. Priority to electric drive 1:9 - STX10/STX20/STX40 1:2 - STX60/STX100 1:7- STX140 1:9 -

orm to EN 12570 standard

bly with ISO 5210 omply with ISO 5211 s available on request

TX models

idrant on larger quarter-turn gearboxes

gher vibration levels)

t lifetime and do not require any specific periodic maintenance

| <b>ATIONS</b>                  | Power supply   | The actuators can operate on a wide variety of power supplies:<br>• 3-phase , single-phase or DC,<br>• up to 690 V,<br>• 50 or 60 Hz   |  |  |  |
|--------------------------------|--|--|--|--|--|
| ELECTRICAL SPECIFICATIONS      | Cable entries  | Standard configuration:<br>• power & signal : 1"1/2 NPT + 2x1"NPT<br>• fieldbus : up to 4x3/4"NPT<br>Other configurations available on request: plugs, adaptors, ISO thread  |  |  |  |
| CTRICF                         | Electrical connection                                    | Ring tongue terminals<br>Internal and external ground rod  |  |  |  |
| ELE                            | Fuse protection  | Primary fuse (6.3 x 32mm - 0.5 A) located on the transformer board<br>Two automatic fuses for low voltages   |  |  |  |
| n And<br>Ensors                | Position   | <ul> <li>Movement read directly on the main shaft (direct mechanical link)</li> <li>Absolute sensor (without battery)</li> <li>Range: 1.5 to 900 turns. (Range above 900 turns available on request)</li> </ul>  |  |  |  |
| POSITION AND<br>TORQUE SENSORS | Torque   | <ul> <li>Torque measured by a dynamometric balance</li> <li>Absolute sensor (without battery)</li> <li>Setting range: 40 to 100% of actuator maximum torque by steps of 1%</li> <li>Reading range: 10 to 100% of actuator range with a resolution of 1%</li> </ul>   |  |  |  |
|                                | Power circuit  | Integral motor reversing starters (electromagnetic contactors for On-Off / Modulating Class III)   |  |  |  |
|                                | Display  | Back-lit graphics display with a choice of 8 different languages   |  |  |  |
|                                | On-off remote<br>Control                                 | Command by<br>• voltage: 10 to 250 V DC/AC (current: 10 mA at 24V)<br>• dry contact (use INTELLI+ auxiliary 24 VDC supply)<br>Isolated by opto-couplers<br>Minimum pulse duration: 100ms<br>Time of rotational direction change: 200ms (factory setting range 50 to 500 ms)  |  |  |  |
|                                | Signalling relays  | <ul> <li>4 relays: each information can be freely selected among a total of 23 available information</li> <li>Contact configuration : normally open or normally closed</li> <li>Minimum current 10mA at 5V</li> <li>Maximum current 5A at 250V AC or 5A at 30VDC (inductive load)</li> <li>Additional 3 relay board on option</li> </ul>   |  |  |  |
| 015                            | Fault relay  | <ul> <li>Normally closed &amp; energized SPDT contact</li> <li>Minimum current 10mA at 5V</li> <li>Maximum current 5A at 250V AC or 5A at 30V DC (inductive load)</li> </ul>   |  |  |  |
| CONTROLS                       | Proportional control<br>Modulating Class III<br>(option) | Input (setpoint) and output (feedback) signals are fully isolated from each other<br>Signal configurations (selectable):<br><ul> <li>Input signal: 4-20 mA - output signal: 4-20mA</li> <li>Input signal: 0-20 mA - output signal: 0-20mA</li> <li>Input signal: 0-10 V - output signal: 0-20mA (0-10V with an external resistance)</li> </ul> <li>Analogue inputs: <ul> <li>in current: impedance of 160 Ohms</li> <li>in voltage: impedance of 11 KOhms</li> </ul> </li> <li>Analogue outputs: <ul> <li>in current: maximum acceptable load of 750 Ohms at 24 VDC supply</li> <li>In voltage: minimum acceptable load of 50 KOhms (with a shunt resistance of 500 Ohms)</li> </ul> </li> |  |  |  |
|                                | Fieldbus Control   | See table on next page   |  |  |  |
|                                | Transmitter (option)                                     | Proportional position (0/4-20 mA) and torque (4-20 mA) feedback board  |  |  |  |
|                                | Signalling continuity<br>(option)                        | Allows to use the display and update the open and closed position information (through the signaling relays or Profibus DP) in case of lack of power supply  |  |  |  |
|                                | Fire protection<br>(option)                              | 30 minutes at 1,000°C<br>Tested to UL1709 criteria   |  |  |  |
|                                | Settings   | Non-Intrusive. All actuator settings and parameters are stored in a non-volatile EEPROM memory. Protection by<br>password. Can be done by local command, infrared link or bluetooth link (For a good safety level, bluetooth link is<br>limited at 10m)  |  |  |  |
|                                | Local selectors  | The INTELLI+ can be fully set via its local display and selectors<br>Does not require any specific setting tool  |  |  |  |
| SETTINGS                       | INTELLIKIT (option)                                      | <ul> <li>INTELLISOFT CD-ROM for laptop PC</li> <li>Infrared module to connect to the laptop (USB) and clip on the actuator window</li> <li>From update 3.00, INTELLISOFT is also able to manage bluetooth link with advanced torque recordings</li> </ul>  |  |  |  |
| SET                            | INTELLI Pocket (option)                                  | From update 3.00, INTELLISOFT is also able to manage bluetooth link with advanced torque recordings<br>Industrial pocket PC (PDA)<br>• Protection: IP65 (option: ATEX II2G EEx ia IICT4)<br>• Shock resistance: 1.2 m (on concrete)<br>• Communication:<br>• with INTELLI+ : Infrared link (40 cm maximum distance)<br>• with PC: bluetooth, IRDA, Wifi (802.11b) as a standard<br>• Optional USB station.<br>• Operating system: Windows Mobile 2005, 64Mb RAM + 256Mb storage card   |  |  |  |

| CONFORMITY TO<br>EC DIRECTIVES | EC Directives   | The actuators comply with:<br>• The 2004/108/EC electromagnetic<br>• The 2006/95/EC C Low Voltage<br>• The following harmonized standard<br>- Generic emission standard-Indu<br>- Generic immunity standard - Indu<br>- Rotating elec¬trical machines E<br>- Degrees of protection provided  |
|--------------------------------|---|--|
| זדגסוב                         | Profibus DPV1<br>(option)   | <ul> <li>PROFIBUS-DPV1 - RS 485</li> <li>Baud rate: 9.6 kbit/s up to 1.5 Mbit/</li> <li>Communication protocol: PROFIBUS</li> <li>Type of connection: single line (star</li> <li>Cable specification: Profibus certifie</li> <li>Line connection without repeater <ul> <li>Actuators per line: 31 max.</li> <li>Line length: 1.2 km max. (0.75 n</li> </ul> </li> <li>Line connection with repeaters <ul> <li>Number of repeaters per line: 9</li> <li>30 actuators and 1 Km max. per</li> <li>Number of actuators per line w</li> <li>Line length with 9 repeaters: 10</li> </ul> </li> <li>Scan speed (30 units 6 1.2 km): 0.1s</li> <li>Power supply: internal and isolated update the open and closed positio</li> </ul> |
| FIELDBUS CONTROLS              | Modbus<br>(option)  | MODBUS RTU - RS 485     Transmission medium: 1 shielded pc     Functions: Half Duplex, asynchrono     Baud rate: 1.2k to 115 Kbit/s     Format: 8 data bits, 1 stop bit, no pc     Communication protocol: Modbus (s     Modbus address: configurable by th  |
|                                | Foundation Fieldbus<br>(option)   | <ul> <li>H1 speed = 31.25kBit/s</li> <li>Fully compliant with fieldbus standa</li> <li>Physical layer: IEC 61158-2, 2 wires</li> <li>Current consumption: 20mA</li> <li>Operating voltage: 9 to 32 VDC</li> <li>Cable specification: Type A (for example)</li> <li>Line connection <ul> <li>Actuators per line without repeter: 1.</li> <li>Number of repeaters per line: 4</li> <li>Maximum number of actuators</li> </ul> </li> </ul>  |
|                                | Please refer to our Technical Har<br>AF401: Quarter-Turn Explosionpr<br>AF402: Multiturn Explosionproof |  |

ic compatibility

ards: ndustrial environment EN 61000-6-4 · Industrial environment EN 61000-6-2 es EN 60034-1, Jed by enclosures (IP code) EN 60529

bit/s (autodetection) BUS DPV1 slave-cyclic & acyclic standard) or redundant line (option) iffied cable only

5 mi)

e: 9 max c. per segment . e with repeater: 124 maximum s: 10.2 km max. (6.2 mi) 0.1s (at a baud rate of 93.75 Kbit/s) ted via INTELLI+. Optional signalling battery or 24VDC external backup supply sition information in case of loss of power supply pproved by PNO (Profibus Nutzer Organisation)

pair cable nous mode, multidrop

parity (slave) the actuator menu

ndard IEC 61158 res communication

xample: 3076F Belden)

epeater: 31 max. r: 1.9 km max. (1.2 mi) e: 4 max. ors and line length depends on consumption available ested. Several DCS manufacturer operability checked.

n electrical data, dimensions and wiring diagrams.



Explosion proof INTELLI+ actuators

*33* / / / /



# Configuration

INTELLI+ offers lot of information, many of them can be configurable by the user as it is shown in the following table.

| INFORMATION   | STANDARD  | CONFIGURABLE  |
|---|---|---|
|   | <ul> <li>Tag number (8 digits)</li> <li>Actuator serial number (unchangeable)</li> <li>Manufacturing date (unchangeable)</li> <li>Password (000)</li> </ul>   | • Password (3 digits)   |
| Close direction<br>Closing mode<br>Setting of torque limit system<br>Closing torque<br>Opening torque setting<br>Only if closing the valve on torque<br>Valve seat torque<br>Torque to unseat the valve | <ul> <li>Clockwise</li> <li>On position</li> <li>100%</li> <li>100%</li> <li>100%</li> <li>100%</li> </ul>  | <ul> <li>Counter-clockwise</li> <li>On torque</li> <li>Other values between 40 and 100%</li> <li>Other values between 40 and 100%</li> <li>Other values between 40 and 100%</li> <li>Other values between 40 and 100% or without any limitation</li> </ul>  |
| Auxiliary remote commands<br>(2 chosen from 10)   | <ul> <li>Local command inhibit but local stop<br/>available (auxiliary command 1)</li> <li>In emergency closing (ESD)<br/>(auxiliary command 2)</li> </ul>  | <ul> <li>Local plus remote control or remote<br/>control only</li> <li>Local or remote control</li> <li>Local command inhibited</li> <li>Open/Close inhibited</li> <li>Auto / modulating / On-Off</li> <li>Emergency closing (ESD)</li> <li>Emergency stopping (ESD)</li> <li>Partial stroke</li> </ul> |
| Fault tolerance degradation (ESD)<br>Auxiliary command activated<br>by a contact  | • None<br>• Normally open   | <ul> <li>No thermal overload (weatherproof versions only)</li> <li>Full torque (100%)</li> <li>Normally closed</li> </ul>   |
| Blue selector operating mode  | <ul> <li>By pulse (a pulse is enough to achieve<br/>an opening or closing command)</li> <li>Authorized</li> </ul>   | <ul> <li>Maintained (actuator operates while<br/>the operator holds the button)</li> <li>Increments from 0 to 100% (actuator<br/>moves the valve to the position set<br/>in % of opening)</li> <li>Inhibited</li> </ul>   |
| Stop local, while remote command  | None  | <ul> <li>Open priority</li> <li>Close priority</li> <li>Open and close priority</li> </ul>  |
| Faults reported on fault relay  | <ul> <li>Control circuit power lost (always included)</li> <li>Fuse blown (always included)</li> <li>Thermal cutoff has tripped (always included)</li> <li>Lost phase (always included)</li> <li>Locked rotor (always included)</li> <li>Loccal / remote selector set to local</li> <li>Local / remote selector set to off</li> </ul> | <ul> <li>Jammed valve</li> <li>Actuator receives an emergency command (ESD)</li> <li>The actuator receives an inhibit command</li> <li>Overtravel</li> <li>4 - 20 mA signal lost (if positioner option installed)</li> </ul>  |

| INFORMATION  | STANDARD  | CONFIGURABLE   |
|--|---|--|
| Information reported<br>on signalling relays           | <ul> <li>Valve open (for R1 and R3)</li> <li>Valve closed (for R2 and R4)</li> </ul>                                  | <ul> <li>Torque limiter action in the opening / closed direction</li> <li>Valve in intermediate position, between x% and y% of opening (for example: 10% to 50%)</li> <li>Selector in local/remote/off</li> <li>The actuator is moving (fixed signal)</li> <li>The actuator is moving (blinking signal)</li> <li>Moving in the open/close direction (fixed signal)</li> <li>Moving in the open/close direction (blinking signal)</li> <li>Emergency command (ESD)</li> <li>Stop mid-travel</li> <li>The actuator is normally powered</li> <li>The motor thermal cutoff has tripped</li> <li>Jammed valve</li> <li>In three-phase, a phase is missing</li> <li>4-20 mR signal lost (if positioner option installed)</li> <li>The handwheel has been activated since the last electrical movement</li> <li>If fieldbus option is installed, this relay is assigned to an external command</li> <li>Battery low (if installed)</li> </ul> |
| Each contact can be:                                   | <ul> <li>Normally open (when something occurs, contact is closed)</li> </ul>  | <ul> <li>Partial stroking in progress / in fault</li> <li>Normally closed</li> </ul>   |
| In case of communication loss                          | • Remain in position  | <ul><li>Go to closed position</li><li>Go to open position</li></ul>  |
| Position remote indication                             | • 4-20mA  | <ul> <li>0-20mA and 0-10V*</li> <li>4-12 mA</li> <li>12-20 mA</li> </ul>   |
| Position remote indication<br>Torque remote indication | • 4-20mA  |  |
| Signal variation direction                             | • Signal increases in the open direction  | • Signal decreases in the open direction   |
| Auxiliary command 1                                    | <ul> <li>Switch: automatic control (proportional<br/>command) / On-Off (standard Open /<br/>Close command)</li> </ul> |  |
| Type of signal   | • 4-20mA  | <ul> <li>0-20mA and 0-10V</li> <li>4-12mA</li> <li>12-20mA</li> </ul>  |
| Signal direction                                       | • Signal increases in the open direction  | • Signal decreases in the open direction   |
| Dead band setting                                      | • 1%  | • Other value between 0.2 and 5%   |
| In case of 4-20mA signal loss                          | • Remain in position  | <ul> <li>Go to fully closed position</li> <li>Go to fully open position</li> </ul>   |

OPENING/

